



Deze download wordt u gratis aangeboden door Pick-upnaalden.nl

Web : www.pickupnaalden.com
Email : info@pick-upnaalden.nl
Facebook : www.facebook.com/pickupnaalden
Twitter : twitter.com/Pickupnaalden
Google+ : https://plus.google.com/+FCaris_pickupnaalden

SERVICE MANUAL

STEREO CD MIDI SYSTEM

SANSUI R-500CD

P-R500 AUTO RETURN TURNTABLE
DA-R500 DOUBLE CASSETTE RECEIVER
CD-R500 COMPACT DISC PLAYER
S-U1 HI-FI SPEAKER SYSTEM



CAUTION

1. Parts identified by the $\triangle$ symbol on the schematic diagram and the parts list are critical for safety. Use only replacement parts that have critical characteristics recommended by the manufacturer.
2. Make leakage-current or resistance measurements to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

Sansui

SANSUI ELECTRIC CO., LTD.

NOTE

1. The symbols, UL, CSA, SA, BS, UK, EU, AS and XX on the parts list and the schematic diagram mean followings respectively.

UL..... Manufactured for U.S.A. market.
(Underwriters Laboratories approved model.)
CSA..... Manufactured for Canadian market.
SA..... Manufactured for South African market.
BS, UK..... Manufactured for United Kingdom market.
EU..... Manufactured for European market.
AS..... Manufactured for Australian market.
XX..... Standard Version.
NON MARK..... Common Parts.

2. Some printed circuit boards are not supplied as the assembled.
To separate these in this service manual, the stock No's are not indicated at the ends of the board names. However, the individual parts on the circuit boards are provided by orders.

AUTO RETURN TURNTABLE

SANSUI P-R500




Specifications


Type.....	Belt drive system
Rated speeds.....	33-1/3, 45 rpm
Platter.....	Plastic platter (diameter 290mm)
Motor.....	DC servo motor
Wow/flutter.....	0.5% (WRMS)
Signal-to-noise ratio.....	Better than 72 dB (DIN-B)
Tonearm.....	Dynamically balanced straight arm
Effective tonearm length...	211.4 mm
Power voltage.....	DC 12V
Power consumption.....	5W
Dimensions.....	340 mm (13-1/4") W 91.5 mm (3-5/8") H 340 mm (13-1/4") D
Weight.....	2 kg (4.4 lbs) net
Pick up	
Type.....	Dual Magnet type
Output voltage.....	2.5 mV (1,000 Hz, 50 mm/sec)
Correct load impedance....	47 kohms
Frequency response.....	20 - 20,000 Hz
Stylus.....	0.6 mil diamond stylus (MG-1971 replacement stylus)

- Design and specifications subject to change without notice for improvements.

1. WIRING DIAGRAM



2. EXPLODED VIEW & PARTS LIST




• Parts List < Exploded View >


No.	Stock No. (J)	Stock No. (T)	Description	Parts No.	Q'ty
1	58311900	MFC1031D07	3mm Ring	B73	3
2	58312000	MSB1611D00	Clutch Plate, Upper	SA123	1
3	58312100	MSB1612D07	Clutch Plate, Cower	SA121-01	1
4	58312200	MFC1032D04	4mm Ring	B74	1
5	58312300	MDK1383D08	45 rpm Adaptor	SK22	1
6	58312400	MDH1215D08	Tone Arm	PA11503	9
6-1	58312500	MTC1003D09	Head Sheel	SE3-02	1
6-2	58312600	MPS0001D09	Stylus	MG1971	1
7	58312700	MMR1048D07	Tone Arm Lifter	SA38-02	1
8	58312800	MDK1381D04	Anti-Skating Knob	SPB131	1
9	58312900	MMS1064D04	Spring	SA133-801	1
10	58313000	MFC1033D01	4mm E Ring	E74	1
11	58313100	MFW1082D02	Washer	CP27-1	1
12	58313200	MSB1613D04	Lever, Cueing	SP133-48	1
13	58313300	MFS1083D05	Screw	3.5×11 BTV	1
14	58313400	MSB1614D01	Arm Clip	SPB36-1	1
15	58313500	MMS1065D01	Spring	SA24-1	1
16	58313600	5210320HO2	Screw	3×20 RB	1
17	58313700	MSB1615D08	Spur, Gear	SA120	1
18	58313800	MSB1616D05	Link, Return	SA24-01	1
19	58313900	GWL0937D00	Switch	SK60-1B	1
20	58314000	MSS1071D08	Stud	SA112A	1
21	58314000	MMS1066D08	Spring	SA110-2-01	1
22	58314200	MSB1617D02	Lever, Return	SP111A	1
23	58314300	MSS1072D05	Cam Stud	SM113-1	1
24					
25	58314500	MFW1083D09	Washer	SE108-2	1
26	58314600	MFC1034D08	3mm E Ring	E73	1
27	58314700	MSB1618D09	Slide Plate, Return	SE108	1
28					
29	58314400	5210208HO3	Screw	2×8 RA	1
30					
31	58314800	MFC1035D05	6mm E Ring,	E76	1
32	58314900	MSB1619D06	Turntable Platter	SA52-01	1
33	58315000	MPF1377D08	Belt	SA70	1
34	58315100	MSB1620D04	Spindle	SB55	1
35	58315200	MFW1084D06	Poly Washer	SA56-1	1
36	58315300	MFW1085D03	Oil Cup	SA55-1	1
37	58311800	MDS1313D02	Cabinet	SE302	1
38	58315400	MEJ1281F09	Connector	IC25057	1
39	58315500	MEJ1284D04	Pcb-Output	ST32-1A	1
40	58315600	MSB1621D01	Rubber Cap	MK302-1	1
41	58315700	MPF1373D00	Rubber Mat	SA51-02	1
42	58315800	MSB1622D08	Reject (Plastic)	MK107-2	1
43	58316000	MMS1067D05	Spring	MK64	1
44	58315900	MSB1623D05	Reject (Plastic)	MK107-3	1
45	58316100	5210308HO6	Screw	3×8 RB	5
46	58316200	5210310HO1	Screw	3×10 RB	9
47	58311400	MMS1056D07	Spring, Stand	SE306-2	4
48	58311500	MPF1368D04	Rubber, Stand	ST306	4
49	58311600	MPF1369D01	Collar, Stand	STB306-4	4
50	58311700	5270318IO6	Screw	3×18TA	4
51	58316300	MFW1086D00	Spring Washer	5/32	1
52	58316500	MSB1624D02	Cug	SM26-1	1
53	58316400	MFN1017D09	Nut	KZ4	1
54	58316600	MSB1625D09	Reject (Plastic)	MK107-1	1
55	58316700	MDK1382D01	Knob, Reject	SE106-01	2
56	58311000	MSH1055D00	Dust Cover	SE301	1
57	58311100	MCF1014D00	Cushion-Dust Cover	CL301-2B	1
58	58311200	MSB1609D05	Hinge	SE304	1
59					
60	58316800	MSB1626D06	Wiper, Reject	SKB109-2	1
61	58316900	MFS1084D02	Screw	2.6×11 R1	1
62	58317000	MSB1627D03	Cushion, Motor	SA93-1	1
63	58317100	MMS1068D02	Collar	SA93	1
64	58317200	MMP1051D07	Pulley, Motor	CK95	1
65	58317300	MTP0005D02	Motor	SA100-01	1
66	58317400	MDS1221D05	P.V.C. Plate (Function Lens)	SE29-5011	1
67					
68					
69	58317500	GWP0938D01	Mini Push Switch	CKB61	1
70	58317600	GPA0003D03	P.C. Board	VR50315-1	1
71	58311300	MSB1610D03	Base Case	SE303	1
72	58317700	MMS1069D09	Spring	SE110	1
73					
74	58310900	MDT1323D03	"SANSUI" Mark Plate		1

3. OTHER PARTS

Front View




Top View




No.	Stock No. (J)	Stock No. (T)	Description
1	58312300	MDK1383D08	45 Rpm
2	58315100	MSB1620D04	Spindle
3	58315700	MPF1373D00	Rubber Mat
4	58314900	MSB1619D06	Turntable Platter
5	58316700	MDK1382D01	Knob Reject
6	58311000	MSH1055D00	Dust Cover
7	58312500	MTC1003D09	Head Shell
8	58312400	MDH1215D08	Tone Arm
9	58312700	MMR1048D07	Tone Arm Elevator
10	58313200	MSB1613D04	Lever, Cueing
11	58315400	MET1281F09	Connector
12	58315000	MPF1377D08	Belt

4. PACKING LIST

No.	Stock No. (J)	Stock No. (T)	Description
1	58310300	MPW1084D09	Poly Bag For Set
2	58310500	MPP1266D08	Styrofoam Packing for set
3	58310200	MPC1471D06	Carton Case
4	58310400	MDL2326D01	Instruction Book



DOUBLE CASSETTE RECEIVER

SANSUI DA-R500**Specifications****Audio section****Power output**

Min. RMS, both channels driven from 35 to 20,000 Hz with no more than 0.5% total harmonic distortion
20 watters per channel into 4 ohms

Total harmonic distortion.. less than 0.5% at or below rated min. RMS power output

Load impedance..... 4-8 ohms

Input sensitivity and Impedance (1 kHz)

PHONO..... 2.5 mV/47 kohms

VIDEO S./AUX..... 150 mV/47 kohms

CD..... 500 mV/47 kohms

Frequency response (at 1 watt)

..... 20 to 20,000 Hz, +3 dB, -3 dB

Signal to noise ratio (short-circuit, A-network)

PHONO..... 72 dB

CD/VIDEO S./AUX..... 90 dB

FM section

Tuning range..... 88 to 108 MHz

Usable sensitivity

Mono IHF..... 10.8 dBf (1.9 μ V: T-100)

DIN..... 0.9 μ V

50 dB quieting sensitivity

Stereo..... 37 dBf

Signal to noise ratio (at 65 dBf)

Stereo..... 60 dB

Distortion (at 65 dBf)

Stereo..... less than 0.35% at 1,000 Hz

Stereo separation..... 40 dB at 1,000 Hz

AM section

Tuning range..... 520 to 1,710 kHz

Units with MW, LW switch

MW..... 522 to 1611 kHz

LW..... 153 to 360 kHz

Usable sensitivity (Loop antenna)

..... 58 dB/m

Signal to noise ratio..... 45 dB

Tape section

Track format..... 4-track 2-channel system

Wow/flutter..... 0.35% max (WRMS)

Signal to noise ratio

..... Better than 50 dB

Frequency-response (-20 VU recording/playback)

Normal Tape (LH)..... 125 to 10,000 Hz $\pm$ 3dB

Power requipment..... AC 110 ~ 120V/220V ~ 240V (50/60 Hz)

for U.S.A. (UL)..... AC 120V (60 Hz)

UK (BS)..... AC 240V (50 Hz)

220V area..... AC 220V (50/60 Hz)

Power consumption..... 140 watts

Dimensions..... 340 mm (13-1/4") W

345 mm (13-5/8") D

210 mm (8-1/4") H


Weight..... 7.2 kg (15.8 lbs) net

8.2 kg (18.0 lbs) packed


- Design and specifications subject to changes without notice for improvements.

1. BLOCK DIAGRAM

1-1. Tuner Section




1-2. Cassette Deck REC/P.B Amp. & Audio Amp. Section




2. INTERIOR BLOCK DIAGRAM OF IC


• TA7784P (Pre-Amp. IC)




• LA3220 (ALC & 2 Channel Equalizer Amp. IC)




• LA1240 (AM Tuner IC)




• LA6458DS (Dual Operational Amp. IC)




• LA1231N (IF & Quadrature Detector IC)




• TD6301AP (Frequency Display IC)



• LB1403 (Level Meter IC)



• TA7358P (FM Front-End IC)



3. ADJUSTMENTS

3-1. AM And FM Section Adjustment

Note: Test points and adjustment parts are shown in Fig.3-1.

AM - alignment				
	step	connect to	frequency	points of alignment
IF	1	Connect AM loop antenna to ant. terminal and common oscilloscope to TP 8 D.C voltage meter to TP 6	450 KHz	T 8
	2			T 9
	3		repeat alignment 1 & 2	
MW	4		522 KHz	T 6 TP6 for 0.8V
	5		1611 KHz	TC 5 TP6 for 8.0V
	6		repeat alignment 4 & 5	
	7		603 KHz	T 4
LW	8		1404 KHz	TC 4
	9		repeat alignment 7 & 8	
	10		153 KHz	T 7 TP6 for 0.8V
	11		360 KHz	TC 6 TP6 for 8.0V
	12		repeat alignment 10 & 11	
	13		175 KHz	T 5
	14		350 KHz	TC 3
	15		repeat alignment 13 & 14	

FM - alignment				
	step	connect to	frequency	points of alignment
IF	1	Sweep gen. VIA 10pF to TP 1 and common oscilloscope to TP 5	10.7 MHz	T 1
	2			T2, T3 s - curve
	3		repeat alignment 1 & 2 until s-curve is symmetrical	
RF	4	D.C voltage meter to TP 7	87.5 MHz	TP7 for 1.3V
	5		108 MHz	L 2 TP7 for 6.0V
	6	Signal gen. to TP 9.	repeat alignment 4 & 5	
	7		90 MHz	L 1
	8		106 MHz	TC 1
	9		repeat alignment 7 & 8	

MULTIPLEX ALIGNMENT

1. CONNECT "RF OUT" CABLE OF FM-STEREO-GENERATOR 20uV 1 KHz TO ANT. TERMINALS OF RECEIVER AND TURN RECEIVER TO 98 MHz.

2. ADJUST THE MUTE ON WITH VR 1.

MULTIPLEX ALIGNMENT:

GENERAL ALIGNMENT CONDITIONS:

CONNECT "RF OUT" CABLE OF FM - STEREO GENERATOR TO ANT. TERMINALS OF RECEIVER AND TUNE RECEIVER TO 98 MHz
RF - INPUT VOLTAGE SHOULD BE SET SO THAT THE IF AMPLIFIER IS LIMITING.

ADJUST THE FREQUENCY 19 KHz OF TP 4 WITH VR 2.




Fig.3-1 GTB1351D12 (FM/LW, 3-bands) or
GTB1340D03 (FM/AM, 2-bands) P.C. Board

3-2. Cassette Electrical Adjustment

Note: Adjustment parts are shown Fig. 3-7.

Step	Adjustment Item	Test Tape Supply Signal	Mode	Adjustment Point	Result	Remarks
1	DECK A High Speed	3 KHz -10dB Test Tape	DECK A : Play H.S.D SW: ON	VR 207	6040 Hz	S202 Turn to left while adjust speed See Fig 3-3 & 3-7
2	DECK A Norm. Speed	3 KHz -10dB Test Tape	DECK A : Play H.S.D SW: OFF	VR 206	3020 Hz	"
3	DECK B High Speed	3 KHz -10dB Test Tape	DECK B : Play H.S.D SW: ON	VR 205	6000 Hz	"
4	DECK B Norm. Speed	3 KHz -10dB Test Tape	DECK B : Play H.S.D.SW: OFF	VR 204	3000 Hz	"
5	Rec Bias Frequency	Blank Tape	REC / PAUSE	L 201	Normal: 85 KHz Beat: 74 KHz	See Figs 3-4 & 3-7
6	Rec Bias Current	Blank Tape	REC / PAUSE	VR2 (Rch) L202(Rch) VR3 (Lch) L203(Lch)	Normal : 4.0mV Beat : 4.0mV	See Figs 3-5 & 3-7
7	DECK A Level(Rch)	1 KHz 0dB Test Tape	PLAY	VR 201	Output Levels of Rch and Lch Are Equal.	See Figs 3-6 & 3-7




Fig. 3-4 REC Bias Frequency Adjustment




Fig. 3-3 Tape Speed Adjustment




Fig. 3-5 REC Bias Current Adjustment




Fig. 3-1 Head Adjustment




Fig. 3-6 PB Level Adjustment





Fig. 3-7 GPB1337D12 Cassette Deck REC/P.B. Amp. & Audio Amp. P.C. Board

4. PARTS LOCATION & PARTS LIST

4-1. GPB1335D07 LED Indicator P.C. Board (Stock No. 58332300)




• Component Side

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC			
IC401	58334800	EIC0014036	LB 1403
D401,402,407, 58332500		GLD0152553	L.E.D. Green
D403,406 58332600		GLD0162451	L.E.D. Yellow
D404,405,408, 58332400		GLD0142253	L.E.D. Red
C401,402	48459800	ECE107C601	Elect Cap 10 μ F/16V
R401	00224900	ERJ1030415	Resistor 1K ohm 1/4W
R402,403	46479800	ERJ1040612	Resistor 10K ohm 1/6W
R405	46476500	ERJ3920611	Resistor 390 ohm 1/6W

4-2. GPB1334D00 High-Speed Switch P.C. Board (Stock No. 58332200)




• Component Side

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
R501,502	00235700	ERJ4720416	470 ohm 1/4W
S501,502,503	58327900	GWP0918D09	Function Switch

4-3. GPB1344D01 Freq. Display P.C. Board (Stock No. 58336700)



• Component Side


• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC			
IC01	58336900	EIC9147AP3	TC 9147AP
IC02	58337000	EIC0061041	TD 6104AP
IC03	46410100	EIC0063012	TD 6301AP
Transistor			
TR01, 02, 03	07194801	ESC1815G56	2SC 1815GR
Diode			
D01,02,03, 06 58335500		EDS4148124	IN 4148
LED			
D04, 010	58332400	GLD0142253	L.E.D. Red
D05	58332500	GLD0152553	L.E.D. Green
D011	58332600	GLD0162451	L.E.D. Yellow

• Parts List < GPB1344D01 >

Parts No.	Stock No. (J)	Stock No. (T)	Description
D012, 013, 014, 015, 016	58337200	GLD0371521	L.E.D. Green 5 $\varnothing$
C08	48463300	ECE105F105	Elect Cap 0.1 μ F/50V
C09	48463900	ECE106F106	Elect Cap 1 μ F/50V
C07	48464000	ECE226F109	Elect Cap 2.2 μ F/50V
C02, 015	48458900	ECE108B306	Elect Cap 100 μ F/10V
C011	48458400	ECE479ATB4	Elect Cap 4700 μ F/6.3V (H.V)
C013	00382500	ECC221PF04	Ceramic Cap 22pF N150 $\pm$ 10%
C014	00382900	ECC271PF09	Ceramic Cap 27pF N150 $\pm$ 10%
C03	00383200	ECC331PF04	Ceramic Cap 33pF N150 $\pm$ 10%
C04, 05, 010, 017	58337400	ECC104LFK8	Ceramic Cap 103 (SR) $\pm$ 20%
C01, 06, 012, 016	00382800	ECC224FF04	Ceramic Cap 223 + 80% - 20%
R09	00233200	ERJ3320417	Resistor 330 ohm 1/4W
R011	46475600	ERJ1620618	Resistor 160 1/6W
R010	46475900	ERJ2220613	Resistor 220 1/6W
R07	46476100	ERJ2720618	Resistor 270 1/6W
R06,012,013, 014,015,016, 017,018,019, 020,021,022, 023,024,025, 026,028,029, 030,031,032, 033,034,	46476300	ERJ3320613	Resistor 330 1/6W
R08	46478200	ERJ2230614	Resistor 2.2K 1/6W
R01	46479000	ERJ4730613	Resistor 4.7K 1/6W
R02,03,035, 036	46479800	ERJ1040612	Resistor 10K 1/6W
R04	46481000	ERJ3340615	Resistor 33K 1/6W
R05	46482000	ERJ8240617	Resistor 82K 1/6W
R038	46482200	ERJ1050613	Resistor 100K 1/6W
R05	46482400	ERJ1250619	Resistor 120K 1/6W
R037	46484400	ERJ8250618	Resistor 820K 1/6W
SW01,02,03, 04,05,06,07, 08,09,010,011	58336800	GWP0912D07	Momentary Switch
XL01	58327700	ECF0723771	7.2MHz Crystal

4-4. GPB1351D12 Tuner P.C. Board. FM/MW/LW, 3 bands (Stock No. 58345400)



• Component Side

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC			
IC1	58333500	EIC0073585	TA 7358P
IC2	03612300	EIC0012319	LA 1231N
IC3	58333600	EIC1161C39	uPC 1161C
IC4	03608000	EIC0012401	LA 1240
IC5	58333700	EIC6458DX8	LA 6458D
IC6	58333800	EIC0038106	TDA 3810
Transistor			
TR19,20,21	46078601	ESC0732G57	2SC 732GR
TR6,8	58335110	ESC1015G52	2SC 1015GR
TR2,4,5,7,11, 13,14,15,16,25	07194801	ESC1815G56	2SC 1815GR
TR3,26	07273601	ESC1923R52	2SC 1923R
TR9,10	58335200	ESC2120Y51	2SC 2120Y
TR17,18	03703400	ESK0163D26	2SK 163
TR1,12	46898202	ESK0212E75	2SK 212E
TR24	58331200	ESCA950Y51	2SA 950Y
T1	58334300	ETF0103092	FM I.F.T.
T2	58347600	ETD0116106	FM I.F.T.
T3	58347700	ETD0126107	FM I.F.T.
T4	58334200	ETE0010102	MW RF Coil
T5	58336400	ETE0025108	LW RF Coil
T6	58333900	ETA0362070	MW OSC Coil
T7	58336500	ETG0011075	LW OSC Coil
T8	58334100	ETM0759073	AM I.F.T.
T9	58334000	ETM0760071	AM I.F.T.
VR1	58333100	ERH104A018	Semi-VR 10K ohm
VR2	58333000	ERH503A015	Semi-VR 5K ohm
L1,2	58334700	ELL0051D00	FM OSC/RF Coil
L3	58335000	ETL022UH17	Chock Coil 22μH
L4,5	58334900	ETL040MH11	Chock Coil 40mH


• Parts List < GPB1351D12 >

Parts No.	Stock No. (J)	Stock No. (T)	Description
Diode			
VD1,2	58335400	EDV1310019	KV 1310
VD4,5	58335300	EDV1236010	KV 1236Z
D1,2,3,4,5,6,7, 8,9,10,11,12, 13,14,15,16, 17,18,20,21	58335500	EDS4148124	IN 4148
CF1,2	58333300	ECF1071815	FM 10.7 MHz Ceramic Filter
CF3	58333400	ECF450A216	AM 450A Ceramic Filter (Double)
BPF1	58333200	ECF8810848	FM Band Pass Filter
TC5,6	58332900	ECT0101420	Trimmer 10pF Yellow
TC1,3,4	58332800	ECT0301220	Trimmer 30pF Red
C7	00384100	ECC500IF02	Ceramic AP 5pF ± 10%
C3,56	00381200	ECC101PF01	Ceramic AP 10 N150 ± 10%
C9	58335700	ECC301PF05	Ceramic AP 30 N150 ± 10%
C127	00383700	ECC471IF07	Ceramic AP 47pF ± 10%
C11,20,83,85, 96,126	00381300	ECC102IF06	Ceramic AP 100 ± 10%
C99,104	00382600	ECC222IF09	Ceramic AP 220 ± 10%
C4,5,6,8,63, 76,81,124	00381400	ECC103JF01	Ceramic AP 102 ± 20%
C129	00383900	ECC473JF03	Ceramic AP 472 ± 20%
C66,69,130	00381500	ECC104FF07	Ceramic AP 103 +80% - 20%
C14,16,19,22, 29,51,62,71	58335800	ECC224FF00	Ceramic AP 223 +80% - 20%
C32	00383700	ECC472IF08	Ceramic AP 470 ± 10%
C59	00383200	ECC332IF09	Ceramic Ap 330 10%
C72	00358100	ECS152JF15	Poly Cap 150pF ± 5% 50V
C73	00360600	ECS472JF12	Poly Cap 470 ± 5% 50V
C45,46,74	00403800	ECP103KF13	Mylar Cap 102 ± 10%
C38,39	00404000	ECP123KF19	Mylar Cap 122 ± 10%
C114,115	00405200	ECP393KF14	Mylar Cap 392 ± 10%
C47,48	00405400	ECP473KF15	Mylar Cap 472 ± 10%
C43,44	00405800	ECP683KF12	Mylar Cap 682 ± 10%
C33	00407800	ECP474KF16	Mylar Cap 473 ± 10%
C112,113	00406600	ECP154KF19	Mylar Cap 153 ± 10% 50V
C121	00407000	ECP224KF17	Mylar Cap 223 ± 10% 50V
C107	00407400	ECP334KF17	Mylar Cap 333 ± 10% 50V
C84,94,110, 111	00408600	ECP105KF15	Mylar Cap 104 ± 10% 50V
C119	00406200	ECP104KF14	Mylar Cap 103 ± 10% 50V
C125,82	00300900	ECE106N604	Elect Cap 1μF NP
C42	58335900	ECE225L602	Elect Cap 0.22μF/16V (CLC)
C93,95	58336000	ECE475L601	Elect Cap 0.47μF/16V (CLC)
C41	48463900	ECE106F601	Elect Cap 1μF/16V (CLC)
C26,27,34,40, 67	58336100	ECE336L603	Elect Cap 3.3μF/16V (CLC)
C2,18,21,23, 36,37,49,50, 98,103	58336600	ECE226L603	Elect Cap 2.2μF/16V (CLC)
C65,97,102, 116,120	58336200	ECE476L602	Elect Cap 4.7μF/16V (CLC)
C29,30,70,80, 90,92	48459800	ECE107C601	Elect Cap 10μF/16V
C123	48460100	ECE477C809	Elect Cap 47μF/16V
C13,24,31,68, 91,108,118, 101	48460200	ECE108C808	Elect Cap 100μF/16V
C35,100,109	48460300	ECE228C801	Elect Cap 220μF/16V
C122	48460500	ECE478CCB7	Elect Cap 470μF/16V
R84,162	46476100	ERJ2720618	Resistor 270 ohm 1/6W
R94,100	46474300	ERJ4710611	Resistor 47 1/6W
R7,11	46475100	ERJ1020610	Resistor 100 1/6W
R77,85,164,39	46475900	ERJ2220613	Resistor 220 1/6W
R27	46476300	ERJ3320613	Resistor 330 1/6W
R18	46476500	ERJ3920611	Resistor 390 1/6W
R16	46476900	ERJ5620616	Resistor 560 1/6W
R19	46477200	ERJ8220615	Resistor 820 1/6W
R17,50,55,92, 95	46477400	ERJ1030611	Resistor 1K 1/6W
R10	46477800	ERJ1530616	Resistor 1.5K 1/6W

• Parts List < GPB1351D12 >

Parts No.	Stock No. (J)	Stock No. (T)	Description		
R40,48,49,83, 118,120,163	46478200	ERJ2230614	Resistor	2.2K	1/6W
R60,64,169, 102	46478600	ERJ3330614	Resistor	3.3K	1/6W
R8,66,70,71, 165,174	46479000	ERJ4730613	Resistor	4.7K	1/6W
R101	46479200	ERJ5630617	Resistor	5.6K	1/6W
R29,81,160, 161	46479600	ERJ8230616	Resistor	8.2K	1/6W
R14,25,28,32, 58,63,70,91, 170,173	46479800	ERJ1040612	Resistor	10K	1/6W
R88	46480000	ERJ1240618	Resistor	12K	1/6W
R105,109,82, 171,56	46480200	ERJ1540617	Resistor	15K	1/6W
R21,22,23,15, 36,41,42,52, 35,87,89,172	46480600	ERJ2240615	Resistor	22K	1/6W
R80	46480800	ERJ2740610	Resistor	27K	1/6W
R43,44,75, 106,110	46481000	ERJ3340615	Resistor	33K	1/6W
R31,34,39,45, 46,176	46481400	ERJ4740614	Resistor	47K	1/6W
R67	46481600	ERJ5640618	Resistor	56K	1/6W
R38,78,79	46482200	ERJ1050613	Resistor	100K	1/6W
R47	46482600	ERJ1550618	Resistor	150K	1/6W
R72	46482800	ERJ1850616	Resistor	180K	1/6W
R73	46483800	ERJ4750615	Resistor	470K	1/6W
R9	46484600	ERJ1060614	Resistor	1M	1/6W
R20	00224700	ERJ1010413	Resistor	10 ohm	1/4W
R5	00230300	ERJ2210416	Resistor	22	1/4W
R93,133,136	00224800	ERJ1020414	Resistor	100	1/4W
R74	00227600	ERJ1520419	Resistor	150	1/4W
R142	00233200	ERJ3320417	Resistor	330	1/4W
R103,134,166, 140	00235700	ERJ4720416	Resistor	470	1/4W
R12	00238200	ERJ6820413	Resistor	680	1/4W
R3,68,115, 127,138,167	00224900	ERJ1030415	Resistor	1K	1/4W
R53,54	00227700	ERJ1530410	Resistor	1.5K	1/4W
R53,54,65	00230500	ERJ2230418	Resistor	2.2K	1/4W
R116,126	00231900	ERJ2730413	Resistor	2.7K	1/4W
R24	00233300	ERJ3330418	Resistor	3.3K	1/4W
R113,125	00234600	ERJ3930416	Resistor	3.9K	1/4W
108,111	00235800	ERJ4730417	Resistor	4.7K	1/4W
R139	00237100	ERJ5630411	Resistor	5.6K	1/4W
R141	00239500	ERJ8230410	Resistor	8.2K	1/4W
R26,30,61,62, 59,69,145, 148,149,150	00225000	ERJ1040416	Resistor	10K	1/4W
R147,151,154	00227800	ERJ1540411	Resistor	15K	1/4W
R158	00229200	ERJ1840410	Resistor	18K	1/4W
R33,37,51,144, 146,152,157	00230600	ERJ2240419	Resistor	22K	1/4W
R122,124	00232000	ERJ2740414	Resistor	27K	1/4W
R107,112	00235900	ERJ4740418	Resistor	47K	1/4W
R4,6,014,128, 131,143,153	00225100	ERJ1050417	Resistor	100K	1/4W
R129,130	00227900	ERJ1550412	Resistor	150K	1/4W
R137	00236000	ERJ4750419	Resistor	470K	1/4W
R132,135	00237300	ERJ5650413	Resistor	560K	1/4W
△ R57,75, △ 76, △ 13, △ 114, △ 117	00119800	ERJ102F221	Resistor	100 ohm	1/2W
	58347000	MEJ1288M02	3 Pin Plug		Plug "0"

4-5. GPB1340D03 Tuner P.C. Board. FM/AM, 2 bands (Stock No. 58332100)



• Component Side

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC			
IC1	58333500	EIC0073585	TA 7358P
IC2	03612300	EIC0012319	LA 1231N
IC3	58333600	EIC1161C39	uPC 1161C
IC4	03608000	EIC0012401	LA 1240
IC5	58333700	EIC6458DX8	LA 6458D
IC6	58333800	EIC0038106	TDA 3810
Transistor			
TR19,20,21	46078601	ESC0732G57	2SC 732GR
TR6,8	58335110	ESC1015G52	2SC 1015GR
TR2,4,5,7,11, 13,14,15,16	07194801	ESC1815G56	2SC 1815GR
TR3	07273601	ESC1923R52	2SC 1923R
TR9,10	58335200	ESC2120Y51	2SC 2120Y
TR17,18	03703400	ESK0163D26	2SK 163
TR1,12	46898202	ESK0212E75	2SK 212E
TR24	58331200	ESCA950Y51	2SA 950Y
T1	58334300	ETF0103092	FM I.F.T.
T2	58347600	ETD0116106	FM I.F.T.
T3	58347700	ETD0126107	FM I.F.T.
T4	58334200	ETE0010102	MW RF Coil
T6	58333900	ETA0362070	MW OSC Coil
T8	58334100	ETM0759073	AM I.F.T.
T9	58334000	ETM0760071	AM I.F.T.
VR1	58333100	ERH104A018	Semi-VR 10K ohm
VR2	58333000	ERH503A015	Semi-VR 5K ohm
L1,2	58334700	ELL0051D00	FM OSC/RF Coil
L3	58335000	ETL022UH17	Chock Coil 22μH
L4,5	58334900	ETL040MH11	Chock Coil 40mH
R40,48,49,83, 118,120,163	46478200	ERJ2230614	Resistor 2.2K 1/6W

• Parts List < GPB1340D03 >


Parts No.	Stock No. (J)	Stock No. (T)	Description		
Diode					
VD1,2	58335400	EDV1310019	KV 1310		
VD4,5	58335300	EDV1236010	KV 1236Z		
D1,2,4,5,6,7, 8,9,10,11,12, 13,14,15,16, 17,18,20,21	58335500	EDS4148124	IN 4148		
CF1,2	58333300	ECF1071815	FM 10.7 MHz Ceramic Filter		
CF3	58333400	ECF450A216	AM 450A Ceramic Filter (Double)		
BPF1	58333200	ECF8810848	FM Band Pass Filter		
TC5	58332900	ECT0101420	Trimmer 10pF Yellow		
TC1,4	58332800	ECT0301220	Trimmer 30pF Red		
C7	00384100	ECC500IF02	Ceramic AP	5pF	±10%
C3,56	00381200	ECC101PF01	Ceramic AP	10 N150	±10%
C9	58335700	ECC301PF05	Ceramic AP	30 N150	±10%
C127	00383700	ECC471IF07	Ceramic AP	47pF	±10%
C11,20,83,85, 96,126	00381300	ECC102IF06	Ceramic AP	100	±10%
C99,104	00382600	ECC222IF09	Ceramic AP	220	±10%
C4,5,6,8,63, 76,81,124	00381400	ECC103JF01	Ceramic AP	102	±20%
C66,69	00381500	ECC104FF07	Ceramic AP	103	±80% 20%
C14,16,19,22, 29,51,62,71	58335800	ECC224FF00	Ceramic AP	223	±80% 20%
C32	00383700	ECC472IF08	Ceramic AP	470	±10%
C59	00383200	ECC332IF09	Ceramic Ap	330	10%
C73	00360600	ECS472JF12	Poly Cap	470	±5% 50V
C45,46,74	00403800	ECP153KF19	Mylar Cap	102	±10%
C38,39	00404000	ECP123KF19	Mylar Cap	122	±10%
C114,115	00405200	ECP393KF14	Mylar Cap	392	±10%
C47,48	00405400	ECP473KF15	Mylar Cap	472	±10%
C43,44	00405800	ECP683KF12	Mylar Cap	682	±10%
C33	00407800	ECP474KF16	Mylar Cap	473	±10%
C112,113	00406600	ECP154KF19	Mylar Cap	153	±10% 50V
C121	00407000	ECP224KF17	Mylar Cap	223	±10% 50V
C107	00407400	ECP334KF17	Mylar Cap	333	±10% 50V
C84,94,110, 111	00408600	ECP105KF15	Mylar Cap	104	±10% 50V
C119	00406200	ECP104KF14	Mylar Cap	103	±10% 50V
C125,82	00300900	ECE106N604	Elect Cap	1μF NP	
C42	58335900	ECE225L602	Elect Cap	0.22μF/16V	(CLC)
C93,95	58336000	ECE475L601	Elect Cap	0.47μF/16V	(CLC)
C41	48463900	ECE106F601	Elect Cap	1μF/16V	(CLC)
C26,27,34,40, 67	58336100	ECE336L603	Elect Cap	3.3μF/16V	(CLC)
C2,18,21,23, 36,37,49,50, 98,103	58336600	ECE226L603	Elect Cap	2.2μF/16V	(CLC)
C65,97,102, 116,120	58336200	ECE467L602	Elect Cap	4.7μF/16V	(CLC)
C29,30,70,80, 90,92	48459800	ECE107C601	Elect Cap	10μF/16V	
C123	48460100	ECE477C809	Elect Cap	47μF/16V	
C13,24,31,68, 91,108,118, 101	48460200	ECE108C808	Elect Cap	100μF/16V	
C35,100,109	48460300	ECE228C801	Elect Cap	220μF/16V	
C122	48460500	ECE478CCB7	Elect Cap	470μF/16V	
R84,162	46476100	ERJ2720618	Resistor	270 ohm	1/6W
R94,100	46474300	ERJ4710611	Resistor	47	1/6W
R7,11	46475100	ERJ1020610	Resistor	100	1/6W
R77,85,164,39	46475900	ERJ2220613	Resistor	220	1/6W
R27	46476300	ERJ3320613	Resistor	330	1/6W
R18	46476500	ERJ3920611	Resistor	390	1/6W
R16	46476900	ERJ5620616	Resistor	560	1/6W
R19	46477200	ERJ8220615	Resistor	820	1/6W
R17,50,55,92, 95	46477400	ERJ1030611	Resistor	1K	1/6W
R10	46477800	ERJ1530616	Resistor	1.5K	1/6W

• Parts List < GPB1340D03 >

Parts No.	Stock No. (J)	Stock No. (T)	Description		
R60,64,169,102	46478600	ERJ3330614	Resistor	3.3K	1/6W
R8,66,70,71,165	46479000	ERJ4730613	Resistor	4.7K	1/6W
R101	46479200	ERJ5630617	Resistor	5.6K	1/6W
R29,81,160,161	46479600	ERJ8230616	Resistor	8.2K	1/6W
R14,25,28,32,58,63,70,91,173	46479800	ERJ1040612	Resistor	10K	1/6W
R88	46480000	ERJ1240618	Resistor	12K	1/6W
R105,109,82,56	46480200	ERJ1540617	Resistor	15K	1/6W
R21,22,23,15,36,41,42,52,35,87,89	46480600	ERJ2240615	Resistor	22K	1/6W
R80	46480800	ERJ2740610	Resistor	27K	1/6W
R43,44,75,106,110	46481000	ERJ3340615	Resistor	33K	1/6W
R31,34,39,45,46	46481400	ERJ4740614	Resistor	47K	1/6W
R67	46481600	ERJ5640618	Resistor	56K	1/6W
R38,78,79	46482200	ERJ1050613	Resistor	100K	1/6W
R47	46482600	ERJ1550618	Resistor	150K	1/6W
R72	46482800	ERJ1850616	Resistor	180K	1/6W
R73	46483800	ERJ4750615	Resistor	470K	1/6W
R9	46484600	ERJ1060614	Resistor	1M	1/6W
R20	00224700	ERJ1010413	Resistor	10 ohm	1/4W
R5	00230300	ERJ2210416	Resistor	22	1/4W
R93,133,136	00224800	ERJ1020414	Resistor	100	1/4W
R74	00227600	ERJ1520419	Resistor	150	1/4W
R142	00233200	ERJ3320417	Resistor	330	1/4W
R103,134,166,140	00235700	ERJ4720416	Resistor	470	1/4W
R12	00238200	ERJ6820413	Resistor	680	1/4W
R3,68,115,127,138,167	00224900	ERJ1030415	Resistor	1K	1/4W
R53,54	00227700	ERJ1530410	Resistor	1.5K	1/4W
R53,54,65	00230500	ERJ2230418	Resistor	2.2K	1/4W
R116,126	00231900	ERJ2730413	Resistor	2.7K	1/4W
R24	00233300	ERJ3330418	Resistor	3.3K	1/4W
R113,125	00234600	ERJ3930416	Resistor	3.9K	1/4W
108,111	00235800	ERJ4730417	Resistor	4.7K	1/4W
R139	00237100	ERJ5630411	Resistor	5.6K	1/4W
R141	00239500	ERJ8230410	Resistor	8.2K	1/4W
R26,30,61,62,59,69,145,148,149,150	00225000	ERJ1040416	Resistor	10K	1/4W
R147,151,154	00227800	ERJ1540411	Resistor	15K	1/4W
R158	00229200	ERJ1840410	Resistor	18K	1/4W
R33,37,51,144,146,152,157	00230600	ERJ2240419	Resistor	22K	1/4W
R122,124	00232000	ERJ2740414	Resistor	27K	1/4W
R107,112	00235900	ERJ4740418	Resistor	47K	1/4W
R4,6,014,128,131,143,153	00225100	ERJ1050417	Resistor	100K	1/4W
R129,130	00227900	ERJ1550412	Resistor	150K	1/4W
R137	00236000	ERJ4750419	Resistor	470K	1/4W
R132,135	00237300	ERJ5650413	Resistor	560K	1/4W
△ R57,75, △ 76, △ 13, △ 114, △ 117	00119800	ERJ102F221	Resistor	100 ohm	1/2W
58347000	MEJ1288M02	3 Pin Plug	Plug "0"		

4-6. • GPB1337D12 Cassette Deck REC/P.B. Amp. & Audio Amp. (Stock No. 58345900)

- **Component Side**



• Parts List < GPB1337D12 >

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC			
IC201	58329900	EIC0077848	TA 7784P
IC202	46899000	EIC0032207	LA 3220
IC203	58330000	EIC0064581	6458DS
△ IC204	58325900	EIC0041315	STK 4131 - II
IC205	58325800	EIC078M067	78M06
Transistor			
T201,202	58330900	ESCC536F79	2SC 536F
T203	07194800	ESC1815G56	2SC 1815GR
T204,205,214, 216	58330800	ESC2120Y51	2SC 2120Y
T206,207,209	58331500	ESC1012F69	2SC 1012F
T208	03053601	ESC0734F69	2SC 734F
T211	58331200	ESCA950Y51	2SA 950Y
T212	58331100	ESC5610C62	Hit 5610C
T213,215	58331000	ESC5609C64	Hit 5609C
Diode			
D201,202,203, 204,205,206, 207,208,209, 210,219,220	58331300	EDS4148124	IN 4148
D211	58330700	EDS4002424	IN 4002
D212,213,214, 215	58330600	EDS5402423	IN 5402
△ D216	58041000	ERBW005D02	W 005
D217,218	58331400	EDZ1200008	12V
L201	58330200	ETC0012067	Rec Osc Coil Toe 1206
L202,203	58330100	ETL018MH09	Chock Coil 18mH Lch 1206
VR201	58330300	ERH502A014	Semi-Fix 500 ohm 8mm
VR204,205, 206,207	58330400	ERH203A014	Semi-Fix 2K ohm 8mm
VR202,203	58330500	ERH105A019	Semi-Fix 100K ohm 8mm
C237,238	00384200	ECC5611F01	Ceramic Cap 56pF ± 10%
C229,256,257	00381300	ECC1021F06	Ceramic Cap 100pF ± 10%
C222,223	00382000	ECC1521F01	Ceramic Cap 150pF ± 10%
C211,212,260, 262	00382600	ECC2221F09	Ceramic Cap 220pF ± 10%
C265,276,277, 304	00383800	ECC472NF00	Ceramic Cap 470pF ± 10%
C284,291,292, 293,294,298, 299,300,301	00381400	ECC104FF07	Ceramic Cap 103pF +80% -20%
C261,248	00382700	ECC224FF00	Ceramic Cap 223pF +80% -20%
C213	00361500	ECS682JF19	Poly Cap 680pF ± 5% 50V
C224	00358200	ECS153JF16	Poly Cap 1500pF ± 5% 50V
C201,204,205, 233,241,242	00403800	ECP103KF13	Mylar Cap 102 pF ± 10% 50V
C216,217,225	00406200	ECP104KF14	Mylar Cap 103pF ± 10% 50V
C272,273,274, 304	00408600	ECP105KF15	Mylar Cap 104pF ± 10% 50V
C253,254	00406800	ECP184KF18	Mylar Cap 183pF ± 10% 50V
C285,290	00404600	ECP223KF16	Mylar Cap 222pF ± 10% 50V
C226,251,253	00405400	ECP473KF15	Mylar Cap 472pF ± 10% 50V
C227,303	00407800	ECP474KF16	Mylar Cap 473pF ± 10% 50V
C309,310	00408400	ECP823KF18	Mylar Cap 822pF ± 10% 50V
C312	48463900	ECE106L600	Elect Cap 1μF/50V CLC
C266,267	48464000	ECE226L603	Elect Cap 2.2μF CLC
C202,203,206, 210,218,219, 220,232,234, 243,244,249, 250,311	48461100	ECE107L601	Elect Cap 10μF/25V CLC
C245,306,308	48464400	ECE227L707	Elect Cap 22μF/50V CLC
C275,276,279	48464300	ECE107F602	Elect Cap 10μF/50V
C207,208	48460000	ECE337C707	Elect Cap 33μF/16V
C236,247,255, 268,269	48460100	ECE477C809	Elect Cap 47μF/16V
C239,240,258, 270,271	48461400	ECE477D806	Elect Cap 47μF/25V


• Parts List < GPB1337D12 >

Parts No.	Stock No. (J)	Stock No. (T)	Description
C281,282	48464600	ECE477FAB1	Elect Cap 47μF/50V
C278	48461500	ECE108DAB6	Elect Cap 100μF/25V
C221,231,246	48460300	ECE228C8B3	Elect Cap 220μF/16V
C209	48460400	ECE338CCB8	Elect Cap 330μF/16V
C280,283,286, 287,289	48460500	ECE478CCB7	Elect Cap 470μF/16V
C228	48459200	ECE478BAB4	Elect Cap 470μF/10V
C288,297	48461900	ECE109DAB9	Elect Cap 1000μF/25V
C295,296	58348100	ECE339ELB3	Elect Cap 3300μF/35V
R306	46516100	ERM2732018	Resistor 2.7K ohm 2W
R301	46243800	ERM1531018	Resistor 1.5K 1W
△ R314, △ R315	00122400	ERJ470F2F5	Resistor 4.7 1/2W (Fuse)
△ R302, △ R303	00233700	ERJ330F4F2	Resistor 3.3 1/4W (Fuse)
R287,288	00119700	ERJ101F208	Resistor 10 1/2W
R289, △ R290	00119800	ERJ102F209	Resistor 100 1/2W
R208	00120800	ERJ1820212	Resistor 180 1/2W
R226	00233700	ERJ3300415	Resistor 3.3 1/4W
R209	00238100	ERJ6810412	Resistor 68 1/4W
R299,304,313	00227600	ERJ1520419	Resistor 150 1/4W
R280,281	00234500	ERJ3920415	Resistor 390 1/4W
R238,268,273	00235700	ERJ4720416	Resistor 470 1/4W
R297,305	00237000	ERJ5620410	Resistor 560 1/4W
R298,221	00239400	ERJ8220419	Resistor 820 1/4W
R277,279,291, 310	00224900	ERJ1030415	Resistor 1K 1/4W
R246,248,265, 272	00226300	ERJ1230411	Resistor 1.2K 1/4W
R225,226,253, 254,274,284, 285,286,293, 312	00230500	ERJ2230418	Resistor 2.2K 1/4W
R275,276	00233300	ERJ3330418	Resistor 3.3K 1/4W
R234,307,308	00235800	ERJ4730417	Resistor 4.7K 1/4W
R255,256	00238300	ERJ6830414	Resistor 6.8K 1/4W
R257,258	00239500	ERJ8230410	Resistor 8.2K 1/4W
R218,232,260, 262,294,309	00225000	ERJ1040416	Resistor 10K 1/4W
R210,227,228, 235,250,251, 263,266	00227800	ERJ1540411	Resistor 15K 1/4W
R212,219,259, 261	00230600	ERJ2240419	Resistor 22K 1/4W
R300	00234700	ERJ3940417	Resistor 39K 1/4W
R220	00235900	ERJ4740418	Resistor 47K 1/4W
R278,282,283, 292	00237200	ERJ5640412	Resistor 56K 1/4W
R224	00238400	ERJ6840415	Resistor 68K 1/4W
R203,204,206, 207,269,270, 271,311	00225100	ERJ1050417	Resistor 100K 1/4W
R213,217,295	00229300	ERJ1850411	Resistor 180K 1/4W
R264,267	00233500	ERJ3350410	Resistor 330K 1/4W
R201,202	46472700	ERJ1010619	Resistor 10 ohm 1/6W
R243,244	46474500	ERJ5610615	Resistor 56 1/6W
R205	46475900	ERJ2220613	Resistor 220 1/6W
R323	46476100	ERJ2720618	Resistor 270 1/6W
R236,239	46476700	ERJ4720612	Resistor 470 1/6W
R237,240	46499600	ERJ6820619	Resistor 680 1/6W
R247,249,321	46478200	ERJ2230614	Resistor 2.2K 1/6W
R229,231,322	46478600	ERJ3330614	Resistor 3.3K 1/6W
R230	46479200	ERJ5630617	Resistor 5.6K ohm 1/6W
R214,216	46479400	ERJ6830610	Resistor 6.8K 1/6W
R222,223	46479800	ERJ1040612	Resistor 10K 1/6W
R211,319	46480600	ERJ2240615	Resistor 22K 1/6W
R215	46481400	ERJ4740614	Resistor 47K 1/6W
R241,242	46481800	ERJ6840611	Resistor 68K 1/6W
R318,320	46482200	ERJ1050613	Resistor 100K 1/6W
R245	46484400	ERJ8250618	Resistor 820K 1/6W
		MEC1070D01	Bare Wire 6 mm
		MEC1109D00	Bare Wire 7 mm
		MEC1071D08	Bare Wire 8 mm
		MEC0822D07	Bare Wire 10 mm
		MEC1082D06	Bare Wire 12.5 mm
		MEC0844D03	Bare Wire 15 mm
		MEC0833D05	Bare Wire 20 mm

• Parts List < GPB1337D12 >

Parts No.	Stock No. (J)	Stock No. (T)	Description
S201	58329800	GWC0924D08	Record/Play Switch
S202	58328500	GWS0926D01	Slide Switch
PLUG "I", "M", "H", "R"	58346900	MEJ1287M05	2 Pin Plug
PLUG "D", "P"	58347000	MEJ1288M02	3 Pin Plug
PLUG "G"	58347100	MEJ1289M09	4 Pin Plug
PLUG "F", "O", "B"	58347200	MEJ1290M07	5 Pin Plug
PLUG "C"	58347300	MEJ1291M04	6 Pin Plug
PLUG "A", "N"	58347400	MEJ1292M01	7 Pin Plug
PLUG "L"	58347500	MEJ1189M06	5 Pin Plug For Player
△ Si202, △ Si203	58328200	EFSA2521T2	Fuse T 1.25A (BEAB)
△ Si201, △ Si204, △ Si205	58328300	EFS1A621T0	Fuse T 1.6A (BEAB)
△ Si204, △ Si205	58328100	EFS2A022F7	Fuse T 2.0A (UL)
△ Si201	58328000	EFS3A022F4	Fuse T 3.0A (UL)
△ Si206, △ 207	58328400	EFS3A151F3	Fuse T 3.15A

4-7. GPB1339D05 Headphone Jack P.C. Board (Stock No. 58328700)




• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
R601,602	46242800	ERM2221015	Resistor 220 ohm 1W
PLUG "K"	58347200	MEJ1290M07	5 Pin Plug
	58326200	MEJ1146D01	Headphone Jack

• Component Side

4-8. GPB1350D04 EQ. Amp. P.C. Board.




• Component Side

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
IC801,802	58326900	EIC0038128	BA 3812
Plug "N"	58347100	MEJ1289M09	4 Pin Plug
C805,806	48463600	ECE335L602	Elect Cap 0.33 μ F CLC
C801,802	48463900	ECE106L600	Elect Cap 1 μ F CLC
C831	48458900	ECE108B801	Elect Cap 100 μ F/10V
C825,826	48459000	ECE228B804	Elect Cap 220 μ F/10V
C817,818	00403800	ECP103KF13	Mylar Cap 102P $\pm 10\%$ 50V
C807,808	00404800	ECP273KF11	Mylar Cap 272P $\pm 10\%$ 50V
C803,804,821	00405800	ECP683KF12	Mylar Cap 682P $\pm 10\%$ 50V
822			
C815,816	00407400	ECP334KF17	Mylar Cap 333P $\pm 10\%$ 50V
C811,812	00407800	ECP474KF16	Mylar Cap 473P $\pm 10\%$ 50V
C809,810	00408600	ECP105KF15	Mylar Cap 104P $\pm 10\%$ 50V
C819,820	00359000	ECS222JF13	Poly Cap 220pF $\pm 5\%$ 50V
C813,814	00361900	ECS822JF15	Poly Cap 820pF $\pm 5\%$ 50V
R801,802,803	46479400	ERJ6830610	Resistor 6.8K ohm 1/6W
804			

4-9. GPB1349D06 EQ. VR. & Tone & Volume P.C. Board. (Stock No. 58331700)




• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
VR901,902, 903,904,905	58326700	EVR1058903	Equalizer 100KB x 2
VR906	58326600	EVR1058800	Volume 100KA x 2 (Tap)
VR907	58326800	EVR1059003	Balance 100KW
SKT "G"	58347800	MEJ1214F14	4 Pin Connector Output
FOR SKT "G"	58347900	MEJ1049D09	4 Pin Wire Socket
C901,902	48459800	ECE107C601	Elect Cap 10 μ F/16V
C903,904	00383800	ECC472NF00	Ceramic Cap 470pF $\pm 10\%$
C905,906	00407800	ECP474KF16	Mylar Cap 473pF $\pm 10\%$ 50V
C905,906	00235800	ERJ4730417	Resistor 4.7K ohm 1/4W
C903,904	00227800	ERJ1540411	Resistor 15K ohm 1/4W
C901,902	46479000	ERJ4730613	Resistor 4.7K ohm 1/6W


5. EXPLODED VIEW OF MECHANANISM ASS'Y & PARTS LIST

5-1. b-side Deck Mechanism Ass'y



• Parts List				
No.	Stock No. (J)	Stock No.	Description	Q'ty
1	58348200	1821 01 60	Main Base Ass'y	1
2	58348300	1821 01 05	Switch Plate	1
3	58348400	1821 01 501	Push Button Actuator Ass'y	1
4	58377100	1821 01 28A	REC Button Lever	1
5	58348500	1821 01 29	Play Button Lever	1
6	58348600	1821 01 30	RWD Button Lever	1
7	58348700	1821 01 31	FF Button Lever	1
8	58348800	1821 01 32	Stop Button Lever	1
9	58348900	1821 01 503	Pause Button Lever Ass'y	1
10	58349000	1821 01 68	RWD Lever	1
11	58349100	1821 01 15	Pause Lever	1
12	58349200	1821 01 16	Pause Lever Spring	1
13	58349300	1821 01 34	Pause Stopper	1
14	58349400	1821 01 23	Button Lever Spring (C)	1
15		1821 01 19	Sub Chassis	1
16	58377200	1821 01 07	Button Lever Spring (A)	1
17	58349500	1821 01 50	Play Button Lever SP (S)	1
18				
19	58349600	1821 01 22	Actuator Spring	1
20	58349700	1821 01 62	Auto Lever	1
21	58349800	1821 01 21	Auto Lever Spring	1
22	58349900	1821 01 49	Button Lever Spring (E)	1
23	58370000	LSA-1115R	Leaf Switch	1
24	58370100	1821 10 38	Switch Actuator SP	1
25				
26	58370200	1829 03 04	Head Panel	1
27	58370300	1829 03 02	Head Base	1
28	58370400	1821 03 301	Sensing Plate Ass'y	1
29	58377300	1821 03 08	E.H. Spring	1
30	58370500	1821 03 12	Head Panel Spring	1
31				
32				
33	58370600	1821 13 05	P.M.E. Screw	2
34	58370700	1821 03 07	Spring	1
35	58370800	1821 04 301	Pinch Roller Ass'y	1
36	58370900	1821 04 08	Pinch Roller Spring	1
37				
38	58371000	1821 39 19	Metal Guide	1
39	58371100	1821 07 319	RF Pulley Arm Ass'y	1
40	58371200	1821 07 04	RF Pulley Arm Spring	1
41	58371300	1821 07 21	RF Arm Coller Screw	1
42	58371400	1821 07 05	RF Belt	1
43				
44	58371500	1821 09 301	Flywheel Ass'y	1
45	58371600	1821 10 515	Reel Base Ass'y	1
46	58371700	1821 10 512	Take-Up Gear Plate Ass'y	1
47	58371800	1867 03 101	Take-Up Roller Gear	1
48	58371900	1821 10 08	T.G. Plate Spring	1
49	58372000	1821 10 57	FF Gear	1
50	58372100	1821 10 42	Back Tension spring	1
51	58372200	1821 10 309	Supply Reel Ass'y	1
52	58372300	1821 10 312	Take-Up Reel Ass'y	1
53	58377400	1821 10 69	Record Safety Lever	1
54	58372400	1821 10 46	Back Tension Spring	1
55	56372500	1821 12 10	Motor Bracket	1
56	58372600	1820 13 08	Motor Rubber	2
57	58372700	1821 12 02	Motor Collet Screw	2
58	58372800	1821 12 32	Motor Pulley	1
59	58372900	1720 09 05	Main Belt	1
60				
61				
62	58373000	1821 13 04	Elect Slide Lever	1
63	58373100	1821 13 02	Elect Slide Lever SP	1
64	58373200	1829 10 01	Pack Spring	1
65				
66	58373300	271-30-112	R.P. Head	1
67	58377500	TC-2131 H	E. Head	1
68	58373400	SHW 2L 51	Motor	1
69				
70	58377600	9076 00 00	Tams Screw M2.0 x 3	1
71	58373500	9179-00-00	C Tapping Screw M2 x 3	1
72	58373600	9180-00-00	C Tapping Screw M2 x 4	3
73	58373700	9677-00-00	P Tapping Blind Screw M2 x 5	5
74				
75				
76	58377700	9821-00-00	Cap Screw M2 x 8	2
77	58373800	9820-00-00	Cap Screw M2 x 7	1
78	58373900	9922-00-00	Azimuth Screw M2 x 7	1
79				
80				
81				
82	58374000	9421-00-00	P Washer Cut 1.2 x 3 x 0.25	2
83	58374100	9888-00-00	P Washer Cut 1.2 x 3 x 0.4	2
84	58374200	9875-00-00	P Washer Cut 1.55 x 3.8 x 0.5	1
85	58374300	9999-00-04	P Washer Cut 2.05 x 4 x 0.5	1
86				
87	58374400	1821 31 07	Operation Lever	8
88	58374500	1821 31 06	B Frame(s)	1
89	58374600	1829 31 03	Button Lever Shaft	1
90	58374700	9982-00-00	Screw (For Camera) M2 x 7	2

5-2. a-side Deck Mechanism Ass'y




• Parts List

No.	Stock No. (J)	Stock No.	Description	Qty
1	58348200	1821 01 60	Main Base Ass'y	1
2	58348300	1821 01 05	Switch Plate	1
3	58348400	1821 01 501	Push Button Actuator Ass'y	1
4	58348500	1821 01 29	Play Button Lever	1
5	58348600	1821 01 30	RWD Button Lever	1
6	58348700	1821 01 31	FF Button Lever	1
7	58348800	1821 01 32	Stop Button Lever	1
8	58348900	1821 01 503	Pause Button Lever Ass'y	1
9	58349000	1821 01 68	RWD Lever	1
10	58349100	1821 01 15	Pause Lever	1
11	58349200	1821 01 16	Pause Lever Spring	1
12	58349300	1821 01 34	Pause Stopper	1
13	58349400	1821 01 23	Button Lever Spring (C)	1
14	58349500	1821 01 19	Sub Chassis	1
15	58349600	1821 01 50	Play Button Lever SP (S)	1
16	58349700	1821 01 22	Actuator Spring	1
17	58349800	1821 01 62	Auto Lever	1
18	58349900	1821 01 21	Auto Lever Spring	1
19	58350000	1821 01 49	Leaf Switch	1
20	58350100	1821 10 38	Switch Actuator SP	1
21	58350200	1821 03 10	Head Panel	1
22	58350300	1821 03 02	Head Base	1
23	58350400	1821 03 301	Sensing Plate Ass'y	1
24	58350500	1821 03 12	Head Panel Spring	1
25	58350600	1821 13 05	P.M.E. Screw	2
26	58350700	1821 03 07	Spring	1
27	58350800	1821 04 301	Pinch Roller Ass'y	1
28	58350900	1821 04 08	Pinch Roller Spring	1
29	58351000	1821 39 19	Metal Guide	1
30	58351100	1821 07 319	RF Pulley Arm Ass'y	1
31	58351200	1821 07 04	RF Pulley Arm Spring	1
32	58351300	1821 07 21	RF Arm Coller Screw	1
33	58351400	1821 07 05	RF Belt	1
34	58351500	1821 09 301	Flywheel Ass'y	1
35	58351600	1821 10 515	Reel Base Ass'y	1
36	58351700	1821 10 512	Take-Up Gear Plate Ass'y	1
37	58351800	1867 03 101	Take-Up Roller Gear	1
38	58351900	1821 10 08	T.G. Plate Spring	1
39	58352000	1821 10 57	FF Gear	1
40	58352100	1821 10 42	Back Tension Spring	1
41	58352200	1821 10 309	Supply Reel Ass'y	1
42	58352300	1821 10 312	Take-Up Reel Ass'y	1
43	58352400	1821 10 46	Back Tension Spring	1
44	58352500	1821 12 10	Motor Bracket	1
45	58352600	1820 13 06	Motor Rubber	1
46	58352700	1821 12 02	Motor Coller Screw	2
47	58352800	1821 12 32	Motor Pulley	1
48	58352900	1720 09 05	Main Belt	1
49	58353000	1821 13 04	Elect Slide Lever	1
50	58353100	1821 13 02	Elect Slide Lever SP	1
51	58353200	1829 10 01	Pack Spring	1
52	58353300	271-30-112	R.P. Head	1
53	58353400	SHW 2L 51	Motor	1
54	58353500	9179-00-00	C Tapping Screw M2x3	1
55	58353600	9180-00-00	C Tapping Screw M2x4	3
56	58353700	9679-00-00	P Tapping Blind Screw M2x5	5
57	58353800	9820-00-00	⊕ ⊖ CAP Screw M2x7	1
58	58353900	9922-00-00	Azinuth Screw	1
59	58354000	9421-00-00	P Washer Cut 1.2x3x0.25	2
60	58354100	9888-00-00	P Washer Cut 1.2x3x0.4	2
61	58354200	9875-00-00	P Washer Cut 1.55x3.8x0.5	1
62	58354300	9999-00-04	P Washer Cut 2.05x4x0.5	1
63	58354400	1821 31 07	Operation Lever	5
64	58354500	1821 31 06	B Frame(s)	1
65	58354600	1829 31 03	Button Lever Shaft	1
66	58354700	9982-00-00	Screw (for Camera) M2x7	2

6. OTHER PARTS


6-1. Front View




• Parts List

No.	Stock No. (J)	Stock No. (T)	Description
△ 1	58322600	GWA0898D08	Power Switch
2	58321700	MDK1336D04	Cassette Key
3	58321100	MDC1283D06	Cassette Cover (L)
	58321200	MDC1284D03	Cassette Cover (R)
4	58322400	MTC008P017	Counter
5	58323100	MDK1330D02	H.S.D. Knob
6	58327300	GDT0921515	Display For Frequency
7	58320800	MDK1359D07	Preset Knob
8	58320700	MDK1342D18	Tuning Knob Up. Down
9	58320500	MDK1358D00	Function Knob
10	58319200	MDK1334D00	Balance, Volume Knob
11	58319000	MDK1332D06	Equalizer Knob
12	58326200	MEJ1146D01	Headphone Jack

6-2. Top View



6-3. Bottom View




• Parts List < Top & Bottom View >


No.	Stock No. (J)	Stock No. (T)	Description
1	58320400	MDC1304D08	Front Panel
2	58323700	MDC1278D00	Side Panel (L)
3	58323800	MDC1281D02	Side Panel (R)
△ 4	58325005	GTP0173D07	Power Transformer (UK, BS)
△	58325002	GTP0176D08	Power Transformer (UL)
△	58325001	GTP1078D02	Power Transformer (XX)
5	58326300	MEJ1229D03	Speaker Socket
6	58326400	MEJ1083D01	TV/CD Socket
7	58324600	MEJ1185D08	Antenna Socket
△ 8	58324000	EWP0251100	AC Cord 120V (XX, UL)
△	58324100	EWP0251100	AC cord 240V (UK, BS)
9			Rear Panel
△ 10	58328400	EFS3A151F3	Fuse 250V F3, 15A (EU, USA)
△ 11	58328100	EFS2A022F7	Fuse 250V 2A (UL, XX)
△	58328300	EFS1A621T0	Fuse 250V 1.6A (UK, BS)
△ 12	58328000	EFS3A022F4	Fuse 250V F3A (XX, UL)
△	58328300	EFS1A621T0	Fuse 250V 1.6A (UK, BS)
△ 13	58328200	EFS2A2521T2	Fuse 250V T1.25A (EU, BS)

7. DISASSEMBLY


7-1. To Remove Cabinet Top.




7-2. To Remove Base Board.



7-3. To Remove Side Panel From Front Panel.



8. EXPLODED VIEW & PARTS LIST




• Parts List < Exploded View >


No.	Stock No. (J)	Stock No. (T)	Description	Q'ty
1	58318700	MDS1196D04	Cassette Lens (A)	1
2	58318800	MDS1197D01	Cassette Lens (B)	1
3	58321100	MDC1283D06	Cassette Cover (L)	1
4	58321200	MDC1284D03	Cassette Cover (R)	1
5	58345100	MMS1070D07	Eject Spring	2
6	58321700	MDK1336D04	Cassette Key (B)	9
7	58321800	MDK1335D07	Cassette Key (A) For Play	1
8	58322200	MDK1336D15	Cassette Key (B) For Rec	1
9	58323100	MDK1330D02	H. S. D. Knob	3
10	58319300	MDS1202D00	Level Lens	1
11	58320400	MDC1304D08	Front Panel	1
12	58323600	MDT1319D04	Reflector For Front Panel	2
13	58321900	MMS1063D07	Spring For Knob	11
14	58320500	MDK1358D00	Function Knob	9
15	58319200	MDK1334D00	Balance Knob	1
16	58319100	MDK1333D03	Volume Knob	1
17	58318900	MDK1331D09	Power Knob	1
18	58319500	MDS1219D11	Dial Lens (3B)	1
19	58319000	MDK1332D06	Equalizer Knob	5
20	58320700	MDK1342D18	Tuning Knob (DOWN)	1
21	58320600	MDK1342D07	Tuning Knob (UP)	1
22	58320800	MDK1359D07	Preset Knob Cap	8
23	58321300	MSB1550D04	Angle Plate	5
24				
25	58323000	5240310I07	Screw For Deck & Panel & Gear Bracket	7
26	58332200	GPA1334D09	Function Switch P. C. Board	1
27	58323300	MSB1579D09	Bracket (R) For Function Switch P. C. Board	1
28	58323400	MSB1580D07	Bracket (L) For Function Switch P. C. Board	1
29	58325600	MEC1114D06	Deck Earth Terminal	3
30	58345200	5270204I04	Screw For Terminal	1
31				
32				
33	58322500	5240308I02	Screw For Counter BKT. Power BKT. EQ. & LED & Display P. C. Board	9
34	58331700	GPA1349D05	EQ. P. C. Board	1
35	58328700	GPA1339D04	Headphone P. C. Board	1
36	58321400	MSB1592D02	Bracket For Power & Phono	1
△ 37	58322600	GWA0898D08	Power Switch	1
38	58322300	5060306B03	Screw For Bracket & AMP PCB, REC Bracket & PCB Bracket (D), SW. & Bracket	6

• Parts List < Exploded View >

No.	Stock No. (J)	Stock No. (T)	Description	Q'ty
39	58332300	GPA1335D06	LED Display P. C. Board	1
40	58332700	MPE1265D00	LED spacer 1W	12
41	58322000	MSB1482D08	Gear	2
42	58322100	MSB1483D05	Gear Bracket	2
43	58322400	MTC008P017	Counter	1
44	58325700	MPF0804D08	Counter Belt	1
45	58345400	GPA1351D11	Tuner P. C. Board (3B)	1
46	58337100	MSB1585D02	LED Spacer 5W	1
47	58345500	MSB1586D09	LED Holder 3W	1
48	58336700	GPA1344D00	Freq. Display P. C. Board	1
49	58323500	MSB1577D05	LED Holder	1
50	58321500	MSB1548D09	Bracket For Counter	1
51	58345600	5060304B09	Screw for Counter	2
52	58345700	MDK1385D02	Preset Bracket Knob Ass'y (B)	1
53	58321000	MDK1343D04	Preset Bracket Knob Ass'y (A)	1
54	58322800	MSB1556D06	Bracket for P.C. Board (D)	1
55	58318600	MDC1280D05	Base	1
56	58345800	5320311I05	Screw for Base & Cabinet	6
57	58322900	MSB1596D00	Bracket for P.C. Board (C)	1
58	58345900	GPA1337D11	Amplifier P.C. Board	1
59	58346000	MSB3006D00	Rec Wire Bracket	1
60	58326400	MEJ1083D01	TV/CD Socket	1
61	58326300	MEJ1229D03	Speaker Socket	1
62	58326000	5270314H05	Screw For Power IC & Heat Sink	2
63				
64	58326100	5270308I05	Screw For Heat Sink Panel & Side Cabinet	9
65				
66	58328900	MFC0037D02	Fuse Holder	14
67		MES1043D08	Heat Sink For Eener IC	1
△ 68	58325005	GTP0173D07	Power Transformer	1
69	58346100	MPF1386D02	Cabinet Foot	4
70	58323700	MDC1278D00	Side Cabinet (L)	1
71	58323800	MDC1281D02	Side Cabinet (R)	1
72				
73	58319700	5270308H02	Screw For Rear & Heat Sink & Side Cabinet	6
74	58346200	5060306H01	Screw For Rear & Bracket	2
75	58324800	5240308H09	Screw For Rear & Socket	6
76	58324600	MEJ1185D08	Antenna Socket	1
77	58324900	5060408H08	Screw For Rear & Transformer	4
78	58318500	MSB1597D07	Top Cover	1
79	58320900	MMI1057D01	Pointer For Volume	1




9-2. Tuner Section (FM/AM, 2 bands).



- 2SA950Y
- 2SA1015
- 2SC536
- 2SC732
- 2SC1815
- 2SC1923
- 2SC2120
- 2SK212
- 2SK163
- TDA3810
- TC9147P
- TD6301AP
- TA7358P
- uPC1161
- LA1240
- LA1231
- TD6104P
- LA6458D/LA6458DS


is Safety Part
Use only replacement parts
recommended by the manufacturer

9-3. Tuner Section (FM/MW/LW, 3 bands).




- 2SA950Y
- 2SA1015
- 2SC536
- 2SC732
- 2SC1815
- 2SC1923
- 2SC2120
- 2SK212
- 2SK163
- TDA3810
- TC9147P
- TD6301AP
- TA7358P
- uPC1161
- LA1240
- LA1231
- TD6104P
- LA6458D/LA6458DS

10. WIRING DIAGRAM



11. PACKING LIST


No.	Stock No. (J)	Stock No. (T)	Description
1	58317900	MPW1086D03	Poly Bag For Set
2	58318000	MPP1268D02	Styrofoam Packing For Set
3	58317800	MPC1469D01	Carton Case



12. ACCESSORY LIST

No.	Stock No. (J)	Stock No. (T)	Description
1.	58318300	MEA1017D02	AM Loop Antenna
2.	58318400	MEJ1267D03	AM Antenna Wire
3.	58318100	MDL2330D00	Instruction Book

COMPACT DISC PLAYER

SANSUI CD-R500**Specifications****Typical Audio Performance**

Number of Channels..... 2
 Frequency Range..... 20 - 20,000 Hz, $\pm$ 0.3 dB
 Dynamic Range..... 96 dB
 Signal-to-Noise Ratio..... 96 dB
 Channel Separation..... 94 dB (at 1000 Hz)
 Total Harmonic Distortion 0.003% (at 1000 Hz)
 Wow and Flutter..... Quartz crystal precision
 D/A Conversion..... 16-bit equivalent through quadruple oversampling with digital filter and two 14-bit D/A converters

Error Correction System.... Cross interleaved Reed Solomon Code (CIRC)

Audio Output Level..... 2V rms

Optical Readout System

Laser..... semi-conductor AlGaAs
 Wave length..... 800 nm

Signal Format

Sampling Frequency..... 44.1 KHz
 Quantization..... 16 bit linear/channel

Power Supply

Mains Voltage..... See the type plate at the rear of the player

Power Consumption..... 10 W

Safety Requirements..... IEC

Cabinet, general

Material/finish..... Plastic and polystyrene with printing

Dimensions..... 340 mm W(13-1/4")
 350 mm D (13-3/4")
 82 mm H (3-1/4")


Weight..... 3kg (6.6 lbs)

Cautions concerning handling of the laser

A. Cautionary points to minimize danger.

1. Since the laser beam is extremely dangerous when viewed directly at its source, do not look directly at the laser pick-up assembly when the laser beam is being output. Additionally, even when viewing the laser beam only, be sure that you are at least 30 cm away from it when it is in operation.
2. When the laser beam is in operation, do not bring any part of your body into direct contact with or inclose proximity to the convex lens.

B. The following label has been affixed to the unit, listing the proper procedure for working with the laser beam.



CAUTION -INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.
 VORSICHT! UNSICHTBARE LASERSTRAHLUNG TRITZ AUS, WENN DECKEL GEÖFFNET UND WENN SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT IST NICHT DEM STRAHL AUSSETZEN!
 VARNING -OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRR ÄR URKOPPLAD STRÅLEN ÄR FÄRLIG.
 ADVARSEL-USYNLIG LASERSTRÅLING VED ÅBNING, NÄR SIKKERHEDSAFBRYDERE ER UD E AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.

PRODUCT IS CERTIFIED BY THE MANUFACTURER TO COMPLY WITH DHHS RULES 21 CFR SUBCHAPTER J APPLICABLE AT THE DATE OF MANUFACTURE.

MANUFACTURED:

August, 1986

(U.S.A. only)

CLASS 1
LASER PRODUCT




CAUTION

TO PREVENT ELECTRIC SHOCK AND PLAYER MISOPERATION ONLY THE TWO TRANSIT SCREWS SHOULD BE REMOVED. REPLACE WHEN TRANSPORTING UNIT.

ATTENTION

RETIREZ LES DEUX VIS DE FIXATION. CES VIS ONT ETE ETUDIEES POUR MAINTENIR LE MECHANISME DANS UNE POSITION STABLE LORS DU TRANSPORT DE L'APPAREIL.



1. SERVICING HINTS

For servicing hints of the CD mechanism and the servo + preamplifier PCB see Service Manual C.D.M.-2

The set consists of various MOS ICs.

Because in general ICs are very sensitive to overloading and too high voltages, the highest care should be taken during servicing.

See the information enclosed in the packaging of the ICs for further instructions.

In the set chip components have been applied.

For disassembly and assembly of chip components see the figure below.

The disc should always rest properly on the turntable.

To achieve this a disc hold-down has been mounted in a bracket of the tray mechanism.

If the tray mechanism has to be disassembled for servicing, one or more than one separate disc hold-downs should be used.

The set can function normally then.

Code number of the disc hold-down is 4822 532 60906.

When the tray mechanism has been disassembled the player can be prepared for measurements via interconnection of connector pins 22-2 () and 22-3 (Sin) on the control + display PCB.

SERVICE AIDS

Audio test disc	4822 397 30085
Disc without errors + disc with DO errors, black spots and fingerprints	4822 397 30096
Torx screwdrivers	
Set (straight)	4822 395 50145
Set (square)	4822 395 50132
Disc hold-down	4822 582 60906
7th order filter	4822 395 30204




Fig. 1-1

DISASSEMBLY OF TOP COVER

- Remove the 4 screws out of side walls of top cover.
- Remove screw at rear of top cover.
- Take top cover cover from set.

REPLACEMENT OF GLASS FUSE 1701

- Remove top cover.
- The glass fuse is situated on the mains switch PCB in the left-hand rear corner of the set.

REPLACEMENT OF TRANSFORMER FUSE

- Remove top cover.
- Remove screening cap that has been placed over transformer.
- Now the transformer fuse is accessible.
- Reapply the screening cap after fuse exchange.

SERVICING OF THE FRONT PANEL

Disassembly of front panel

- Remove top cover.
- Remove the 3 fixing screws at upper side of front panel.
- Now the front panel can be taken off.
- Ensure during mounting that the 3 bosses of the set frame engage with the appropriate holes of the front panel.

Disassembly of control + display PCB

- The control + display PCB can be taken out after removal of the 5 screws.

SERVICING OF THE DECODER + POWER SUPPLY PCB

- Remove top cover.
- Remove the 2 screws on the decoder + power supply PCB.
- Remove the 2 screws at the upper side of the cooling bracket.
- Remove the screw in the backcover for fixation of the 2 CINCH sockets.
- After the connectors have been disconnected the decoder + power supply PCB can be slid forwards and be taken out of the player.

SERVICING OF THE SERVO + PREAMPLIFIER PCB (see Fig.1-2)

- Remove top cover.
- Remove the front panel.
- Remove screw 4N x 10 and ring item no. 222 (see exploded view of cabinet) at the rear of the tray mechanism.
- Now the tray mechanism/CDM/servo + pre-ampl. PCB assy can be taken out of the frame and can be placed vertically in the appropriate servicing supports in the frame (see Fig 1-2).
- In this way measurements and adjustments can be performed on the servo + preampl. PCB.
- See Service Manual C.D.M. -2 for measurements and adjustments on the servo + preampl. PCB.
- Ensure during mounting of the tray mechanism/CDM/servo + preampl. PCB assy that the suspension rubbers and springs item no. 218 and 219 are present (see exploded view of cabinet).




Fig.1-2

SERVICING OF THE TRAY MECHANISM/CDM/SERVO + PREAMPL. PCB ASSY

- Disassemble top cover.
- Disassemble front panel.
- Remove screw 4N x 10 and ring item no. 222 (see exploded view cabinet) at the rear of the tray mechanism.
- Now the assy can be taken out of the set after the connectors have been disconnected.
- Remove screw N4 x 8 and bracket item no. 501 (see exploded view of tray mechanism).
- The CDM + servo + preampl. PCB is kept in place by a boss of the tray mechanism. If this boss, in the region of the foil connector is bent away the CDM + servo + preampl. PCB can be taken out of its support points of the tray mechanism.
- Ensure during mounting of the CDM/servo + preampl. PCB in the tray mechanism that the mechanical brake item no. 123 (see exploded view of tray mechanism) is positioned properly.

SERVICING OF THE TRAY MECHANISM

Disassembly of the tray mechanism




Fig.1-3

- Remove disc hold-down holder J by disassembling coil spring at rear. Then holder J can be taken out of its hinge points.
- Remove belt D.

- Disassemble pulley B after clamping ring on shaft has been removed.
- Remove lifting bracket N by elevating lug M and sliding bracket out of its shaft guiding.
- Remove gearwheel G by removing shaft K after ring L has been taken away.
- Now disc carrier O can be taken out of the holder by lifting it at the front and sliding it out of the guiding.
- Next cog wheel C, switch bracket E and gearwheel F can be removed successively.
- The tray motor with belt wheel A can be taken out by removing the spring.

Assembly of tray mechanism

- Place disc carrier O in guiding and slide it in place (= disc carrier in position "close").
- Mount gearwheel F.
- Apply switch bracket E. The left-hand boss of the bracket should be positioned between the 2 switches.
- Ensure that the aperture in gearwheel F is vertical (see Fig.1-3) and apply cog wheel C in the way described in Fig.1-4.




Fig.1-4

- Turn cog wheel C counterclockwise till its final position and ensure that the boss of switch bracket E engages with the guiding at the rear of the cog wheel. Turn the cog wheel counterclockwise and clockwise and check if both switches are switched on alternately.
- Turn cog wheel C counterclockwise so that the upper switch is operated and mount pulley B in this position. Next apply the clamping ring.
- Mount gearwheel G and apply shaft K and clamping ring L. Ensure that gearwheel G is positioned before shaft and clamping ring are mounted.
- Apply lifting bracket N. Ensure that the fork at the right of the lifting bracket encloses the guide rail of the tray.
- Mount the motor with pulley A and apply belt D.
- Next hold-down holder J and the compression spring can be mounted.
- Check after mounting the working of the tray mechanism by turning pulley B counterclockwise and clockwise.

2. ELECTRICAL MEASUREMENTS AND ADJUSTMENTS

For measurements and adjustments on the CD mechanism and the servo + preampl. PCB see the CDM-2 Service Manual

Specification measurement




Fig. 2-1

To measure the specification use can be made of audio test disc 4822 397 30085.

Use 7th order filter 4822 395 30204 (see Fig.1-4) to measure:

- Total harmonic distortion (THD)
- Intermodulation distortion
- Signal-to-noise ratio (S/N)

Changing the transformer connections




Fig. 2-2

If the set should be connected to a mains voltage that deviates from the voltage mentioned on the type plate, the transformer connections should be changed, as indicated in Fig. 2-2.

Attention

In case of a change to 110V or 127V the glass fuse on the mains switch PCB should be changed from 200mA-T to 400 mA-T.

DETAILED MEASURING METHOD FOR THE DECODER CIRCUIT

HINTS

Test discs

It is important to treat the test discs with great care. The disorders on the discs (black spots, fingerprints, etc.) are exclusive and unambiguously positioned. Damage may cause additional drop-outs etc. rendering the intentional errors no longer exclusive. In that case it will no longer be possible to check e.g. the good working of the track detectors.

Measurements on op-amps

In the electronic circuits op-amps have been used frequently. Some of the applications are amplifiers, filters, inverters and buffers.

In those cases where in one way or the other feedback has been applied the voltage difference at the differential inputs converges to zero. This applies to both DC and AC signals. The cause can be traced to the properties of an ideal op-amp ($Z_i = \infty$, $G = \infty$, $Z_o = 0$). If one input of an op-amp is directly connected to ground it will be virtually impossible to measure at the inverting and the non-inverting inputs. In such cases only the output signal will be measurable.

That is why in most cases the AC voltage at the inputs will not be given. The DC voltages at the inputs are equal.

Stimulation with "0" and "1"

During troubleshooting sometimes certain points should be connect to ground or supply voltage. As a result certain circuits can be brought in a desired state thus shortening the diagnosis time. In a number of cases the related points are outputs of op-amps. These outputs are short-circuit-resistant, i.e. they can be brought to "0" or ground without problems. **The output of an op-amp, however, should never be connected directly to the power supply voltage.**

Measurements on microprocessors

Inputs and outputs of microprocessors should **never** be connected directly to the power supply voltage. The inputs and outputs should only be brought to "0" or ground if this is stated explicitly.

Measurements with an oscilloscope

During measurements with an oscilloscope it is recommended to measure with a 1:10 test probe, since a 1:10 probe has a considerably smaller input capacitance than a 1:1 probe.

Selection of ground potential

It is very important to select a ground point that is as close as possible to the test point.

Conditions for injection

- Injection of levels or signals from an **external** source should **never** take place if the related circuit has no supply voltage.
- The injected levels or signals should **never** be greater than the supply voltage of the related circuit.

Continuous burning of the laser

- Bridge capacitor 2174 on the servo + preampl. PCB.
- Connect $\overline{Si}$ (= pin 20 of IC6101 on the servo + preampl. PCB) to ground.
- Switch on the supply voltage.
- Now the laser will burn continuously.

Indication of test points

In the drawings of the diagrams and the PCBs the test points have been indicated by a number (e.g. ①) to which the measuring method refers. In the measuring method below, the symbol (①) has been omitted for the test points indicated.

GENERAL CHECKPOINTS

In the detailed measuring method below a number of general conditions, required for a properly functioning set, will not be mentioned. Before the detailed measuring method is started, these general points should first be checked.

- Ensure that disc and objective are clean (remove dust, fingerprints, etc.) and work with undamaged discs.
- Check if all supply voltages are present and if they have the correct values.
- Check the good working of the two microprocessors by means of their built-in test programme and servicing programme.

Method:

Self-test of the servo μ P

With the self-test the following parts of the μ P are tested:

- RAM
- ROM
- TIMER
- serial I/O interface
- I/O gates
- Interrupt the I²C connection on connector 35-2 on the servo + preampl. PCB.
- Unsolder pins 1, 7, 26 and 27 of the servo μ P.
- Render pin 2 of the servo μ P "low" (ground) and switch on the supply voltage.
- The test starts if pin 2 is rendered "high" again (interrupt the connection to ground).
- If all tests are positive, pin 1 of the servo μ P will go low within 1s.

Self-test of the control and display μ P

With this self-test the following parts of the μ P are tested:

- RAM
- ROM
- TIMER
- serial I/O interface
- I/O gates
- Interrupt the I²C connection on connector pin 21-4 on the control + display PCB.
- Render pin 2 of the control display μ P "low" (ground) and switch on the supply voltage.
- The test starts if pin 2 is rendered "high" again (= interrupt the connection to ground).
- If all tests are positive, pin 1 of the control + display μ P will go "low" again within 1s.

Initiation of the servicing programme of the μ P

- Servicing position "0"

Simultaneously depress the PREVIOUS, NEXT and TIME/TRACK keys. Keep these three keys depressed while the mains voltage is switched on.

This is the STAND-BY mode, "0" appears on the display.

In this state it is possible to move the arm by means of the SEARCH FORW and SEARCH REV keys with a minimum torque to the outside and the inside resp. This enables a check of the free motion of the arm across the disc.

- Servicing position "1"

From servicing position "0" the player can be brought in servicing position "1" by depressing the NEXT key.

In this state the laser emits light and the objective starts to focus. When the focal point has been reached, "1" appears on the display.

When **no** disc has been inserted the objective goes 16 x to and fro. Then the player reassumes servicing position "0".

As in servicing position "0" the arm can be moved across the diameter of the disc by means of the SEARCH FORW and SEARCH REV keys.

- Servicing position "2"

To be reached by depressing the NEXT key after servicing position "1" has been reached.

The turntable motor starts to run

On the display appears "2"

In preparation of the transition to servicing position "3" the arm is sent to the centre of the disc

- Servicing position "3"

To be reached by depressing the NEXT key after servicing position "2" has been reached.

The radial control is switched on. The subcode information is ignored. MUTE is high so that the music information **is released**.

On the display appears "3"

(Dependent on the length of the lead-in track music will be reproduced after approx 1 min.)

In this state it is possible to move the arm by means of the SEARCH FORW and the SEARCH REV keys to the outside and to the inside resp. Now the motion is controlled by the μ P and the arm moves by steps of 64 tracks as long as the key is depressed.

If one of the servicing positions 1, 2 or 3 is disturbed (e.g. braking or removing the disc) the player reassumes servicing position "0".

The servicing programme can be left by switching the mains switch (POWER ON/OFF) off and on. (Hardware reset).

I DEMOD IC

- Check the **motor speed**.


See "turntable motor control" in C.D.M.-2 Service Manual, section III.

- Check the **HF signal** on **test point 65 (eye pattern)**.

- Insert a disc.
- The HF signal should be present and be stable in the PLAY mode and in:
 - SERVICING POSITION 3 after the run-in track has been read.
- In SERVICING POSITION 2 and during reading of the lead-in track the RF signal is not stable.

Position of oscilloscope 0,5 μ s/DIV


Amplitude $\approx 1,5V_{pp}$



- Check the **HFD signal** on **test point 97**

- Insert a disc.
- In the PLAY mode and in SERVICING POSITION 3 the HFD signal is "high"; however, minor pulses may be present and in cause of disorders on the disc.
- In SERVICING POSITION 2 and during playback of track no. 15 of test disc 5A HFD pulses are visible.

Position of the oscilloscope 5ms/DIV



- Check the **MUTE signal** on **test point 98**
- Insert a disc.
- In the PLAY mode or in SERVICING POSITION 3 in the **MUTE** signal is "high".
- The **MUTE** signal is "low" in SERVICING POSITIONS 0, 1 and 2, in the STAND-BY (only mains switch depressed) and PAUSE modes and during jumping to a track after command NEXT or PREVIOUS.
- Check the **clock signal** on **test point 71**
- Insert a disc.
- In the Stand-by mode (only mains switch depressed) the frequency of the clock signal is 1,88 MHz.
- In the play mode or in SERVICING POSITIONS 2 or 3 the frequency of the clock signal is 4,32 MHz.

Remark: In SERVICING POSITION 2 the clock signal is unstable.


- Check the **timing signals** destined for the **ERCO IC**.
- Insert a disc.
- Bring the player in one of the following positions SERVICING POSITION 2 or 3 or the PLAY mode

Remark: In SERVICING POSITION 2 the timing signals are unstable.

- Trigger an oscilloscope with the **FSDE signal** on test point 72.
 - Check signals
 - FSDE on test point 72
 - SSDE on test point 76
 - CLDE on test point 77
- and their interrelations


Position of the oscilloscope 20 μ s/DIV

0 = FSDE, tp 72; 1 = SSDE, tp 76; 2 = CLDE, tp 77



Position of the oscilloscope 1 μ s/DIV

0 = FSDE, tp 72; 1 = SSDE, tp 76; 2 = CLDE, tp 77




Remark: The repetition time of the FSDE signal on tp 72 is in the Stand-by mode and in SERVICING positions 0 and 1 : 312 μ s in the PLAY mode and in SERVICING POSITIONS 2 and 3 : 136 μ s

- Check the **DADE signal** on **test point 78**
 - Insert a disc.
 - In the PLAY mode or in SERVICING POSITION 3 activity should be present at test point 78 after the lead-in track has been read.
 - Check the **subcode clock signals**
 - Insert a disc.
 - Bring the player in one of the following positions: SERVICING POSITION 3 or PLAY mode.
 - Trigger an oscilloscope with the FSDE signal on test point 72.
 - Check signals.
 - FSDE on test point 72
 - SWCL/QCLOCK on test point 73
 - SBCL on test point 74
- and measure their interrelations

Positions of the oscilloscope 0,1 ms/DIV

0 = FSDE	tp 72
1 = SWCL/QCLOCK	tp 73
2 = SBCL	tp 74
3 = SBCL	tp 74



Remark: The repetition time of the FSDE signal on tp 72 is: in the STAND-BY mode and in SERVICING POSITIONS 0 and 1 : 312 μ s in the PLAY mode and in SERVICING POSITIONS 2 and 3 : 136 μ s

- Check the **subcode data signals**
- Insert a disc.
- In the PLAY mode or in SERVICING POSITION 3 activity should be present at the following test points.

S-DATA test point 75
Q-SYNC test point 95
Q-DATA test point 96

II ERCO IC

- Check the **timing signals coming** from the **DEMOC IC**
- SEE SUB "I DEMOC IC"
- 'Check the timing signals destined for the ERCO IC'.

- Check the **DADE signal** on **test point 78**
- See sub "I DEMOC IC"
- 'Check the DADE signal on test point 78'


- Check the **CLOX signal** on **test point 94**
- In Stand-by mode (only mains switch depressed) the frequency of the CLOX signal should be 4,2336 MHz.

- Check the **timing signals** destined for the **CIM IC**
- Bring the player in the Stand-by mode (only mains switch depressed).
- Trigger an oscilloscope with the FSEC signal on test point 79.

- Check signals
 - FSEC on test point 79
 - CLEC on test point 80
- and their interrelations

Position of the oscilloscope 20 μ s/DIV

0 = FSEC tp 79
1 = CLEC tp 80




Remark: The repetition time of the FSEC signal is 136 μ s.

- Check the **MUTE signal** on **test point 98**
- See sub "I DEMOC IC"
- 'Check the MUTE signal on test point 98'

- Check the **DAEC signal** on **test point 81**
 - Insert a disc.
 - In the PLAYMODE or in SERVICING POSITION 3 activity should be present at test point 81 after the reading of the lead-in track.
- Check the **MCES signal** on **test point 66**
 - In the Stand-by mode the MCES signal is as indicated in the figure below.

Position of the oscilloscope 50 μ s/DIV



Remark:

The repetition time of the MCES signal is 140 μ s.

- Insert a disc.
- In the PLAY mode or in SERVICING POSITION 3 the MCES signal is as indicated in the figure below.



Remark: The repetition time of the MCES signal is 140 μ s.

Duty cycle is 50%

Also see "Measurement of turntable motor control" in C.D.M.-2 Service Manual, section III.

- Check the **UNEC signal** on **test point 82**
 - Insert test disc 5A.
 - During playback of track no. 17 UNEC flags should briefly be present at test point 82.
- The UNEC flags are also present in case of soft braking of the disc and during fast forward or fast reverse (SEARCH FORW., SEARCH REV.).

Remark: If the UNEC signal at test point 82 remains continuously "high", either the DEMOD IC or the ERCO IC or the RAM IC is defective.

III CIM IC

- Check the **CLOX signal** on **test point 94**.
 - See sub "II ERCO IC".
 - 'Check the CLOX signal on test point 94'
 - Check the **timing signals coming from the ERCO IC**.
 - See sub "II ERCO IC".
 - 'Check the timing signals destined for the CIM IC'
 - Check the **DAEC signal** on **test point 81**.
 - See sub "II ERCO IC".
 - 'Check the DAEC signal on test point 81'
 - Check the **UNEC signal** on **test point 82**.
 - See sub "II ERCO IC".
 - 'Check the UNEC signal on test point 82'
 - Check the **timing signals** destined for the **FIL IC**.
 - Bring the player in the Stand-by mode (only mains switch depressed).
 - Trigger an oscilloscope with the STR1 signal on test point 84.
 - Check signals
 - $\overline{\text{CLEC}}$ on test point 80
 - $\overline{\text{CLCF}}$ on test point 85
 - STR1 on test point 84
- and their interrelations


Position of the oscilloscope 5 μ s/DIV

0 = $\overline{\text{CLEC}}$ tp 80

1 = $\overline{\text{CLCF}}$ tp 85

2 = STR1 tp 84

Remark: The repetition time of the STR1 signal is 22 μ s ($f = 44,1$ kHz).



- Check the **DLCF signal** on test **point 86** and the **DRCF signal** on test **point 87**
 - Insert a disc.
 - In the PLAY mode and in SERVICING POSITION 3 activity should be present at test points 86 and 87 after reading of the lead-in track.

IV FIL IC

- First check all signals round the CIM IC (see "III").
- Check the timing signals
 - Bring the player in the Stand-by mode (only the mains switch depressed).
 - Trigger an oscilloscope with the STR1 signal at test point 84.
 - Check signals

STR1 on test point 84

$\overline{\text{CLCF}}$ on test point 85

$\overline{\text{CLFD}}$ on test point 90

LAT on test point 93

and their interrelations.


Position of the oscilloscope 5 μ s/DIV

0 = STR1 tp 84

1 = $\overline{\text{CLCF}}$ tp 85

2 = $\overline{\text{CLFD}}$ tp 90

3 = LAT tp 93



Remark: The repetition time of the LAT signal is 5,5 μ s. ($f = 176,4$ kHz).

- Check the **DLFD signal** on **test point 91** and the **DRFD signal** on **test point 92**
 - Insert a disc.
 - In the PLAY mode and in SERVICING POSITION 3 activity should be present at test point 91 and 92 after reading of the lead-in track.

V DAC IC



- First check all signals round the FIL IC, see IV.
- Check the output of the OP-AMP after the DAC IC.
- Insert a disc.
- In the PLAY mode and in SERVICING POSITION 3 the analog (= music) signal should be present on the output of the OP-AMP after reading of the run-in track.

VI DEEMPH CIRCUIT


- Insert test disc 5.
- During playback of track no. 14 (recorded without PREEMPH) the DEEMPH signal on connector 43-2 should be "high".
- During playback of track no. 15 (recorded with PREEMPH) the DEEMPH signal on connector 43-2 should be "low".
- During playback of track no. 14 the analog signal should be present at the source of 6320 (to be measured at resistor 3354, tp 67) and 6321 (to be measured at resistor 3355, tp 68).
- During playback of track no. 15 the analog signal should be 0 V at the source of 6320 (to be measured at resistor 3354) and 6321 (to be measured at resistor 3355).

VII KILL CIRCUIT

- During switching on and off of the mains voltage the signal on the collector of 6327 (to be measured on a jumper, tp 69) should be as indicated in the figure below.




3. EXPLODED VIEW OF LOADING ASS'Y AND PARTS LIST



• Parts List				
No.	Stock No. (J)	Description		
101	58374800	4822 464 50401	CHASSIS	
102	58374900	4822 276 11277	2 × SWITCHES	
103	58375000	4822 402 50208	SWITCH BRACKET	
104	58375100	4822 522 31905	CAM WHEEL	
105	58375200	4822 528 81046	BELT WHEEL	
107	58375300	4822 532 50262	RING	
108	58375400	4822 402 40045	LEVEL	
109	58375500	4822 402 20096	DISC	
111	58375600	4822 459 80268	CLAMPER	
112	58375700	4822 492 51725	SPRING	
113	58375800	4822 361 20576	MOTOR + WIRE	
114	58375900	4822 492 63218	WIRE SPRING	
115	58376000	4822 358 20116	BELT	
116	58376100	4822 492 51726	SPRING	
117	58376200	4822 535 91857	PIN	
118	58376300	4822 522 31907	GEAR	
119	58376400	4822 522 31908	GEAR	
121	58376500	4822 462 71375	GUIDES	
122	58376600	4822 466 40176	RUBBER	
123	58376700	4822 402 30143	BRAKE BRACKET	
124	58376800	4822 402 60928	GUIDES	
125	58376900	4822 402 60927	GUIDES	
126	58377000	4822 443 50633	SLIDER	


4. EXPLODED VIEW OF CABINET & PARTS LIST



• Parts List

No.	Stock No. (J)	Stock No. (T)	Description	Q'ty
1	58339500	MDT1344D02	Function Plate	1
2	58339200	MDK1366D30	Knob For "PLAY"	1
3	58339100	MDK1366D29	Knob For "PAUSE"	1
4	58339000	MDK1366D18	Knob For "F.F"	1
5	58338900	MDK1366D07	Knob For "F.B"	1
6	58339900	MMS1061D03	Spring For Knob	4
7	58338600	MDK1364D25	Knob For "TIME/TRACK"	1
8	58338400	MDK1364D03	Knob For "UP"	1
9	58338500	MDK1364D14	Knob For "DOWN"	1
10	58338700	MDK1364D36	Knob For "MEMORY"	1
11	58338800	MDK1365D00	Knob For "OPEN/CLOSE"	1
12	58339800	MMS1062D00	Spring For Knob	5
13	58346300	MMS1060D17	Door Spring	1
14	58339400	MDS1215D02	CD Door Lens	1
15	58339300	MDC1309D03	CD Door	1
16				
17	58337900	MDC1305D05	Front Panel	1
18	58346400	GPB1341D11	Computer P. C. B	1
19	58339700	MSB1573D07	Display Holder	1
20	58332700	MPF1265D00	LED Spacer	2
21	58322500	5240308IO2	Screw For CPU P. C. B	1
22	58340800	5060340BO5	Screw For Side Deck	2
23	58346500	GPA1342D17	Computer LED P. C. B	1
24				
25	58338000	MDC1308D06	Bottom Board	1
26	58338200	MCD1307D09	Side Cabinet (R)	1
27	58346100	MPF1386D02	Cabinet Foot	4
28	58338100	MDC1306D02	Side Cabinet (L)	1
29	58340700	MPF1295D03	Spacer For Side Cabinet	1
30	58341100	GPA0001D09	CD P.C.B & Deck Ass'y	1
31	58326100	5270308IO5	Screw For CD Deck & CDM 2, Heat Sink & P. C. B	1
32				
33	58340300	5270310IO0	Screw For CD & Base	1
34				
35	58346600	5220310IO5	Screw For Transformer	2
36	58340900	GTP0177D05	Power transformer	1
37	58340400	MFW1080D08	Washer For CD	1
38	58341200	GPA0002D06	CD Main P. C. B Ass'y	1
39	58338300	MSB1597D07	Top Cover	1
40	58346700	MFN1002D03	Nut	1
41	58340100	5040308HO3	Screw For Rear/Side/Base, Heat Sink & IC	8
42				
43				
44	58324800	5240308HO9	Screw For RCA Jack	1
45	58319700	5270308HO2	Screw For Heat Sink & Rear	2

5. BLOCK DIAGRAM



• ABBREVIATIONS


B0-B3	- Control bits for radial circuit
DAC	- Current output for track jumping (Digital to Analogue Converted)
DEEMPH	- Deemphasis
DODS	- Drop out detector suppression
D1 ÷ 4	- Photodiode currents
FE	- Focus error signal
FE lag	- Focus error signal for LAG network
HF	- HF output for DEMOD
HFD	- HF detector output for DEMOD
HF-in	- HF current input
I ² C	- Clock signal servo-control μ P
I ² D	- Data signal servo-control μ P
LM	- Laser monitor diode input
LO	- Laser amplifier current output
MCES	- Motor control from ERCO to servo circuit
MUTE	- Mute signal

Q CLOCK	- Subcode clock input for servo μ P
Q DATA	- Subcode data input for servo μ P
Q SYNC	- Subcode synchronization input for servo μ P
RE	- Radial error signal (amplified RE ₂ -RE ₁ currents)
RE1	- Radial error signal 1 (summation of amplified currents D ₃ and D ₄)
RE2	- Radial error signal 2 (summation of amplified currents D ₁ and D ₂)
RE dig	- Radial error digital
RE lag	- Radial error signal for LAG network
RD	- Ready signal, starting up procedure finished
Si	- On/off control for laser supply and focus circuit
TL	- Track loss signal
Vc	- Control voltage for turntable motor

CLDE	- Clock from DEMOD to ERCO
CLEC	- Clock from ERCO to CIM
CLOX	- Clock from CIM (System Clock)
CRI	- Counter reset inhibit
DADE	- Data from DEMOD to ERCO
DAEC	- Data from ERCO to CIM
DEEMPH	- Deemphasis
DLCF	- Data left from CIM to FIL
DRCF	- Data right from CIM to FIL
FSDE	- Frame sync. from DEMOD to ERCO
FSEC	- Frame sync. from ERCO to CIM
HF	- HF input for DEMOD
HFD	- HF detector for DEMOD
I ² C	- Clock signal servo-control μ P
I ² D	- Data signal servo-control μ P
MCES	- Motor control from ERCO to servo
MUTE	- Mute signal
Q CLOCK	- Subcode clock signal
Q DATA	- Subcode data signal
Q SYNC	- Subcode synchronization signal
SBCL	- Subcode bit clock
S DATA	- Subcode data
S-IN	- Tray in
S-OUT	- Tray out
UNEC	- Unreliable data flag from ERCO to CIM

6. SCHEMATIC DIAGRAM, PARTS LOCATION ON P.C. BOARD AND PARTS LIST

6-1. Power Supply Circuit




Circuit Ref. No.	Position
2318	E 9
2397	F 9
2398	F 9
2410	D 7
2411	F 7
2412	B 7
2413	C 7
2414	G 7
2416	D 6
2417	F 6
2418	B 6
2419	C 6
2420	G 6
2421	B 6
2422	A 6
2423	D 6
2424	D 6
2425	D 4
2426	D 4
2427	A 4
2428	B 4
2429	F 5
2430	F 5
3318	D 8
3395	B 9
3396	F 8
3397	F 8
6345	B 8
6346	C 7
6347	F 7
6349	B 5
6350	A 5
6351	D 5
6352	D 5
6353	D 5
6354	D 5
6355	A 5
6356	B 5
6357	G 5
T1	B 2


PRS.00403
T10

6-2. Power Supply & Decoder P.C. Board and Parts List

- **Pattern Side** < **Chip parts** >



- **Component Side**




- **Parts List < Power Supply & Decoder >**

	Stock No. (J)	Stock No. (T)		Stock No. (J)	Stock No. (T)
SAA7000 CIM	58380900	4822 209 10375	1301 X-tal 4,2336 MHz		4822 242 70663
SAA7010 DEMOD	58377800	4822 209 10857			
SAA7020 ERCO	58381000	4822 209 10377	5301	58380000	4822 156 21155
SAA7030 FIL	58381100	4822 209 10378			
TDA1540 DAC	58377900	4822 209 81453	2301,2303 22nF-2%		4822 121 50609
MSM2128-20RS RAM	58378000	4822 209 10379	2370,2371 5,1nF-2%		4822 121 50976
LM833N	58378100	4822 209 83163	2372,2373 1,5nF-2%		4822 121 50432
SN74LS74AN	58378200	4822 209 80782	2374 ÷ 2377 2,2nF-2%		4822 121 50841
MC7805CT	58378300	4822 209 80891	2378,2379 1,2nF-2%		5322 121 54135
MC78M12CT	58378400	5322 209 86176			
MC79M05CT	58378500	4822 209 83164	3311,3318,3320 } 1,8 Ω-NFR25		4822 111 30489
MC7912CT	58378600	4822 209 82065	3321,3346,3389 } 1 Ω-NFR25		4822 111 30483
MC7918CT	58378700	4822 209 83165	3344,3392		
  ©					
BC548B	58378800	4822 130 40937	BU2,3 CINCH-socket	58380100	4822 267 30631
BC818/25 ©	58378900	4822 130 42696	BU4 DIN-socket	58380200	4822 267 40284
BC818/25R ©	58379000	4822 130 42697			
BC848B ©	58379100	5322 130 41982			
BC858BR ©	58379200	4822 130 42134			
BC858CR ©	58379300	4822 130 42634			
BSR56 ©	58379400	4822 130 42633			
 					
IN4002	58379500	5322 130 30684	Miscellaneous		
IN414B	58379600	4822 130 30621	Spring clip	58380300	4822 492 63076
BAX18	58379700	4822 130 34121	Transformer fuse	58380400	4822 252 20007
HZ4B2/C3V9	58379800	4822 130 32843	Mains transf.	58380500	4822 146 21047
BB212	58379900	4822 130 31129	Mains transf. (only for 07/17)	58380600	4822 146 21067

* For Non active chipcomponents, see separate list on page 65.


Circuit Ref.No.	Position																			
1301	F3	2305	D3	2310	D3	2321	E4	2326	D5	2331	C4	2336	C5	2341	C4	2346	C4	2352	D4	
2301	D3	2306	D3	2311	D2	2322	D5	2327	D4	2332	D5	2337	C4	2342	C5	2347	D4	2353	D4	
2302	D3	2307	D3	2313	D2	2323	D4	2328	C5	2333	D4	2338	C5	2343	C4	2348	D4	2354	D4	
2303	D3	2308	C3	2318	D2	2324	D5	2329	D4	2334	C5	2339	C4	2344	C4	2350	D4	2355	D4	
2304	D3	2309	C3	2320	D5	2325	D4	2330	C4	2335	D4	2340	C5	2345	D4	2351	D4	2356	D4	
2357	D4	2362	E3	2370	B5	2375	C4	2380	B4	2385	B4	2392	F3	2400	C2	2410	B2	2416	B1	
2358	C4	2363	E3	2371	C3	2376	B4	2381	B4	2388	F3	2394	E5	2401	C2	2411	A2	2417	B2	
2359	C4	2364	F3	2372	C5	2377	B4	2382	B5	2389	E4	2395	E4	2402	C2	2412	A3	2418	B2	
2360	E1	2365	F1	2373	C4	2378	B5	2383	B4	2390	F3	2396	E5	2403	C2	2413	B3	2419	B2	
2361	E1	2366	F1	2374	B5	2379	B4	2384	B4	2391	F3	2397	E5	2404	C2	2414	F4	2420	F5	
2421	A2	2426	B2	3232	D5	3305	D3	3310	E1	3315	D2	3323	D4	3329	D4	3334	C4	3341	E1	
2422	A2	2427	A2	3301	D2	3306	D3	3311	C3	3318	C2	3324	D5	3330	C4	3335	D4	3342	E1	
2423	B2	2428	A2	3302	D3	3307	D3	3312	D3	3320	D4	3325	D4	3331	C4	3336	C4	3343	E2	
2424	B2	2429	A1	3303	D3	3308	D2	3313	D1	3321	D4	3326	C5	3332	C4	3337	C4	3344	E3	
2425	B2	2430	A2	3304	D3	3309	C3	3314	D2	3322	D5	3328	C5	3333	C4	3340	E1	3345	F3	
3346	F1	3354	C5	3360	B5	3365	B4	3370	A4	3375	A3	3380	C4	3391	F3	3400	B2	3405	C5	
3350	C5	3355	C4	3361	B4	3366	B4	3371	B3	3376	B3	3381	B3	3392	F4	3401	C2	3806	D2	
3351	C4	3356	B5	3362	B4	3367	B4	3372	A4	3377	B3	3385	B4	3393	E4	3402	C2	3808	E4	
3352	B5	3357	C4	3363	B3	3368	A4	3373	A3	3378	C3	3389	E3	3395	E4	3403	B3	3812	F3	
3353	C4	3359	B4	3364	B5	3369	B4	3374	A4	3379	C4	3390	F3	3396	E5	3404	C2	3813	E3	
3814	F3	3831	A5	6304	D4	6310	B3	6316	A3	6323	A4	6328	C2	6338	C2	6343	C2	6351	B2	
3815	E2	5301	D3	6305	E3	6311	F3	6317	B3	6324	A4	6329	B3	6339	C2	6345	E4	6352	B2	
3820	E3	6301	C2	6306	E2	6312	E4	6320	C5	6325	A4	6335	C3	6340	C2	6346	E3	6353	B2	
3826	E4	6302	D2	6308	B5	6313	A2	6321	C4	6326	C4	6336	E1	6341	C2	6349	A2	6354	B2	
3827	E4	6303	D4	6309	B4	6314	A3	6322	A4	6327	B3	6337	E1	6342	C2	6350	A2	6355	A2	
6356	A2																			
6357	A2																			

6-3. Decoder Circuit




	Rel.No.	Position
	6311	E18
	2300	E18
	2302	G 5
	2303	F 2
	2304	F 3
A	2305	G 4
	2306	F 6
	2307	G 6
	2308	F 7
	2309	B 4
	2310	B 5
	2311	C 2
	2312	G 9
	2320	L 9
	2322	G 8
	2323	G 9
	2324	G 9
	2325	L 8
	2326	L 8
	2327	L 8
	2328	L 8
	2329	L 8
	2330	L 8
	2331	L 8
	2332	J 7
	2333	U
	2334	B 8
	2335	P 8
	2336	K 8
	2337	P 8
	2338	P 9
	2339	K 9
	2340	P 9
	2341	K 9
	2342	K 9
	2343	P 9
	2344	K10
	2345	K10
	2346	K10
	2347	P10
	2350	K11
	2351	K11
	2352	P11
	2353	K11
	2354	K11
	2355	K12
	2356	K12
	2357	P12
	2358	L 7
	2359	L 7
	2360	B 7
	2361	B11
	2362	A11
	2363	B15
	2364	B15
	2365	G15
	2366	G15
	2367	G15
	2368	G15
	2369	G15
	2370	A 4
	2371	O14
	2372	O15
	2373	L17
	2374	L14
	2375	N14
	2376	L16
	2377	L16
	2378	L16
	2379	N16
	2380	L17
	2381	L17
	2382	L17
	2383	L17
	2384	L17
	2385	L17
	2386	O12
	2387	F18
	2388	F18
	2389	F18
	2390	B17
	2391	B18
	2392	B20
	2393	B20
	2394	J 2
	2395	T 5
	2400	L19
	2401	L19
	2402	L17
	2403	L17
	2404	L17
	2405	L17
	2406	L17
	2407	L17
	2408	L17
	2409	L17
	2410	L17
	2411	L17
	2412	L17
	2413	L17
	2414	L17
	2415	L17
	2416	L17
	2417	L17
	2418	L17
	2419	L17
	2420	L17
	2421	L17
	2422	L17
	2423	L17
	2424	L17
	2425	L17
	2426	L17
	2427	L17
	2428	L17
	2429	L17
	2430	L17
	2431	L17
	2432	L17
	2433	L17
	2434	L17
	2435	L17
	2436	L17
	2437	L17
	2438	L17
	2439	L17
	2440	L17
	2441	L17
	2442	L17
	2443	L17
	2444	L17
	2445	L17
	2446	L17
	2447	L17
	2448	L17
	2449	L17
	2450	L17
	2451	L17
	2452	L17
	2453	L17
	2454	L17
	2455	L17
	2456	L17
	2457	L17
	2458	L17
	2459	L17
	2460	L17
	2461	L17
	2462	L17
	2463	L17
	2464	L17
	2465	L17
	2466	L17
	2467	L17
	2468	L17
	2469	L17
	2470	L17
	2471	L17
	2472	L17
	2473	L17
	2474	L17
	2475	L17
	2476	L17
	2477	L17
	2478	L17
	2479	L17
	2480	L17
	2481	L17
	2482	L17
	2483	L17
	2484	L17
	2485	L17
	2486	L17
	2487	L17
	2488	L17
	2489	L17
	2490	L17
	2491	L17
	2492	L17
	2493	L17
	2494	L17
	2495	L17
	2496	L17
	2497	L17
	2498	L17
	2499	L17
	2500	L17


6-4. Control & Display Circuit



- **MAB 8441P (Control & Display Micro processor IC)**



6-5. Control & Display P.C. Board and Parts List








• Parts List

Parts No.	Stock No.(J)	Stock No. (T)	Description
IC			
IC101	58341300	EIC0084413	MAB 8441P
	58341400	GDC1501219	Display Red
Diode			
D201	58341500	GLD0311514	L.E.D. Green 3φ
D102	58332400	GLD0142253	L.E.D. Red
D103	58332600	GLD0162451	L.E.D. Yellow
Transistor			
T101, 102	58342200	ESC3284040	C 32840
T103, 104	58342300	ESC3381640	C 33816
Crystal			
XT101	58341600	ECF60M0027	CRYSTAL 6.0MHz
Ceramic			
C104, 105	00383200	ECC331PF04	33pF N150 ±10%
C102, 107	58380700	ECC224LF09	223 SR

• Parts List

Parts No.	Stock No. (J)	Stock No. (T)	Description
Elect			
C103	48463900	ECE106F601	1μF / 50V
C101, 106, 108	48458800	ECE477B709	47μF / 10V
Resistor			
R114	58342700	ERJ100F4F9	1 ohm 1/4W (Fuse)
R101, 107	58342500	ERJ220F4F2	2.2 1/4W (Fuse)
R109	58342600	ERJ330F4F2	3.3 1/4W (Fuse)
R102	00235600	ERJ4710415	47 1/4W
R119	00227600	ERJ1520419	150 1/4W
R112, 118	00233200	ERJ3320417	330 1/4W
R103	00224900	ERJ1030415	1K 1/4W
R105, 106, 110, 117	00235800	ERJ4730417	4.7K 1/4W
R108	00227800	ERJ1540411	15K 1/4W
R104	00225200	ERJ1060418	1M 1/4W
R115, 116	46476300	ERJ3320613	330 1/6W
R111, 113	46479000	ERJ4730613	4.7K 1/6W

7. WIRING DIAGRAM



37523 E 13

8. CIRCUIT REFERENCE SYMBOLS

SYMBOL	DESCRIPTION
	Capacitor. general
	Electrolytic capacitor (+ and - may be omitted)
	Bipolar electrolytic capacitor (+ may be omitted)
	Resistor. general
	N.T.C. resistor
	P.T.C. resistor
	Voltage divider with preset adjustment
	Chip jumper
	Pin contact
	Bus contact
	Coil. self-induction
	Transformer with electrically poor conducting core and adjustable pre-magnetization
	Diode
	Zener diode
	Stabistor
	Double variable capacity diode (in one envelope)
	Photo conductive diode
	L.E.D.

SYMBOL	DESCRIPTION
	Transistor (N.P.N.)
	Transistor (P.N.P.)
	Direct current (DC)
	Alternating current (AC)
	Earth (functional)
	Frame of chassis connection
	Direction in which AC voltages are passed on (optional present)
	Interrupted line
	Not-connected crossing lines
	Connected lines
	Cable tree with lead-outs
	Changer. general (arrow is optional)
	Voltage Controlled Oscillator
	Band-pass filter
	Phase changing network
	Delay element
	Amplifier. general

SYMBOL	DESCRIPTION
	Operational amplifier
	Differential amplifier
	Splitter
	Operational amplifier with open output
	Exclusive OR gate
	True/complement amplifier with high input
	Flip Flop
	AND gate
	OR gate
	Inverter with high input

	0.2W (CR 16)	≤ 220kΩ > 270kΩ	5% 10%
	0.33W (CR 25)	≤ 1 MΩ > 1 MΩ	5% 10%
	0.33W (SFR 25)		5%
	0.25W (VR 25)	≤ 10MΩ > 10MΩ	5% 10%
	0.5W (CR 37)	≤ 1 MΩ > 1 MΩ	5% 10%
	0.67W (CR 52)		5%
	1.15W (CR 68)		5%


* a = 2.5 V
b = 4 V
c = 6.3 V
d = 10 V
e = 16 V
f = 25 V
g = 40 V
h = 63 V
i = 100 V
j = 125 V
k = 160 V
l = 200 V
m = 250 V
n = 300 V
o = 350 V
p = 400 V
q = 500 V
r = 630 V
s = 1000 V
t = 1.6 V
u = 6 V
v = 12 V
w = 15 V
x = 20 V
y = 35 V
z = 50 V
AA = 75 V
AB = 80 V

9. STANDARD CHIP PARTS LIST

©  Chips 50 V NP0 S1206			©  Chips 0,125 W S1206			©  Chips 0,125 W S1206		
1 pF	5%	4822 122 32279	8,2 E	10%	4822 111 90397	9,1 k	5%	4822 111 90373
1,5 pF	5%	4822 122 31792	9,1 E	10%	4822 111 90398	10 k	2%	4822 111 90249
1,8 pF	5%	4822 122 32087	10 E	5%	5322 111 90095	11 k	5%	4822 111 90337
3,3 pF	5%	4822 122 32079	11 E	5%	4822 111 90338	12 k	2%	4822 111 90253
3,9 pF	5%	4822 122 32081	12 E	5%	4822 111 90551	13 k	2%	4822 111 90509
4,7 pF	5%	4822 122 32082	13 E	5%	4822 111 90343	15 k	5%	4822 111 90196
8,2 pF	5%	4822 122 32083	15 E	5%	4822 111 90344	16 k	5%	4822 111 90346
10 pF	5%	4822 122 31971	16 E	5%	4822 111 90347	18 k	5%	4822 111 90238
12 pF	5%	4822 122 32139	18 E	5%	5322 111 90139	20 k	5%	4822 111 90349
18 pF	5%	4822 122 31769	20 E	5%	4822 111 90352	22 k	2%	4822 111 90251
22 pF	10%	4822 122 31837	22 E	5%	4822 111 90186	24 k	2%	4822 111 90512
27 pF	5%	4822 122 31966	27 E	5%	4822 116 60186	27 k	2%	4822 111 90542
33 pF	5%	4822 122 31756	30 E	5%	4822 111 90356	30 k	2%	4822 111 90216
39 pF	5%	4822 122 31972	33 E	5%	4822 111 90357	33 k	5%	5322 111 90267
47 pF	5%	4822 122 31772	36 E	5%	4822 111 90359	36 k	2%	4822 111 90254
56 pF	5%	4822 122 31774	39 E	5%	4822 111 90361	39 k	5%	5322 111 90108
68 pF	5%	4822 122 32267	43 E	5%	5322 116 90125	43 k	5%	4822 111 90363
82 pF	10%	4822 122 31839	47 E	5%	4822 111 90217	47 k	2%	4822 111 90543
100 pF	5%	4822 122 31765	51 E	5%	4822 111 90365	51 k	5%	5322 111 90274
120 pF	5%	4822 122 31766	56 E	5%	4822 116 60187	56 k	2%	4822 111 90573
150 pF	5%	4822 122 31767	62 E	5%	4822 111 90367	62 k	5%	5322 111 90275
180 pF	2%	4822 122 31794	68 E	5%	4822 111 90203	68 k	5%	4822 111 90202
220 pF	5%	4822 122 31965	75 E	5%	4822 111 90371	75 k	2%	4822 111 90574
270 pF	5%	4822 122 32142	82 E	5%	4822 116 60158	82 k	2%	4822 111 90575
330 pF	10%	4822 122 31642	91 E	5%	4822 111 90375	91 k	5%	5322 111 90277
390 pF	5%	4822 122 31771	100 E	5%	5322 111 90091	100 k	2%	4822 111 90214
470 pF	5%	4822 122 31727	110 E	5%	4822 111 90335	110 k	5%	5322 111 90269
560 pF	5%	4822 122 31773	120 E	5%	4822 111 90339	120 k	2%	4822 111 90568
680 pF	5%	4822 122 31775	130 E	5%	4822 111 60164	130 k	2%	4822 111 90511
820 pF	5%	4822 122 31974	150 E	5%	5322 116 90098	150 k	5%	5322 111 90099
1 nF	10%	5322 122 31647	160 E	5%	4822 111 90345	160 k	2%	5322 111 90264
1,2 nF	5%	4822 122 31807	180 E	5%	5322 111 90242	180 k	2%	4822 111 90565
1,5 nF	10%	4822 122 31781	200 E	5%	4822 111 90348	200 k	5%	4822 111 90351
2,2 nF	10%	4822 122 31644	220 E	5%	4822 111 90178	220 k	5%	4822 111 90197
2,7 nF	10%	4822 122 31783	240 E	5%	4822 111 90459	240 k	2%	4822 111 90215
3,3 nF	10%	4822 122 31969	270 E	5%	4822 111 90154	270 k	5%	4822 111 90302
4,7 nF	10%	4822 122 31784	300 E	5%	4822 111 90156	300 k	5%	5322 111 90266
5,6 nF	10%	4822 122 31916	330 E	5%	5322 111 90106	330 k	2%	4822 111 90513
6,8 nF	10%	4822 122 31976	360 E	1%	4822 111 90288	360 k	2%	4822 111 90515
10 nF	10%	4822 122 31728	390 E	5%	5322 111 90138	390 k	5%	4822 111 90182
12 nF	10%	5322 122 31648	430 E	2%	4822 111 90362	430 k	5%	4822 111 90168
15 nF	10%	4822 122 31782	470 E	5%	5322 111 90109	470 k	5%	4822 111 90161
18 nF	10%	4822 122 31759	510 E	5%	4822 111 90245	510 k	5%	4822 111 90364
22 nF	10%	4822 122 31797	560 E	5%	5322 111 90113	560 k	5%	4822 111 90169
33 nF	10%	4822 122 31981	620 E	5%	4822 111 90366	620 k	2%	4822 111 90213
100 nF	20%	4822 122 31947	680 E	5%	4822 111 90162	680 k	2%	4822 111 90368
			750 E	5%	4822 111 90438	750 k	5%	4822 111 90369
			820 E	5%	4822 111 90171	820 k	5%	4822 111 90205
			910 E	5%	4822 111 90372	910 k	5%	4822 111 90374
			1 k	5%	5322 111 90092	1 M	2%	4822 111 90252
			1,1 k	5%	4822 111 90294	1,1 M	5%	4822 111 90408
			1,2 k	5%	5322 111 90096	1,2 M	10%	4822 111 90409
			1,3 k	5%	4822 111 90244	1,3 M	10%	4822 111 90411
			1,5 k	5%	4822 111 90151	1,5 M	10%	4822 111 90412
			1,6 k	5%	5322 111 90265	1,6 M	10%	4822 111 90413
			1,8 k	5%	5322 111 90101	2 M	10%	4822 111 90415
			2 k	5%	4822 111 90165	2,2 M	10%	4822 111 90185
			2,2 k	2%	4822 111 90248	2,4 M	10%	4822 111 90416
			2,4 k	5%	4822 111 90289	2,7 M	10%	4822 111 90417
			2,7 k	2%	4822 111 90569	3 M	10%	4822 111 90418
			3 k	5%	4822 111 90198	3,3 M	10%	4822 111 90191
			3,3 k	5%	4822 111 90157	3,6 M	10%	4822 111 90419
			3,6 k	5%	5322 111 90107	3,9 M	10%	4822 111 90421
			3,9 k	2%	4822 111 90571	4,3 M	10%	4822 111 90422
			4,3 k	5%	4822 111 90167	4,7 M	10%	4822 111 90423
			4,7 k	5%	5322 111 90111	5,1 M	10%	4822 111 90424
			5,1 k	5%	5322 111 90268	5,6 M	10%	4822 111 90508
			5,6 k	2%	4822 111 90572	6,2 M	10%	4822 111 90426
			6,2 k	2%	4822 111 90545	6,8 M	10%	4822 111 90328
			6,8 k	2%	4822 111 90544	7,5 M	10%	4822 111 90427
			7,5 k	5%	4822 111 90276	8,2 M	10%	4822 111 90329
			8,2 k	5%	5322 111 90118	9,1 M	10%	4822 111 90428
©  Chips 0,125 W S1206								
0 E	jumper	4822 111 90163						
1 E	10%	4822 111 90184						
1,1 E	10%	4822 111 90377						
1,2 E	10%	4822 111 90378						
1,3 E	10%	4822 111 90379						
1,5 E	10%	4822 111 90381						
1,6 E	10%	4822 111 90382						
1,8 E	10%	4822 111 90383						
2 E	10%	4822 111 90384						
2,4 E	10%	4822 111 90507						
2,2 E	10%	4822 111 90385						
2,7 E	10%	4822 111 90386						
3 E	10%	4822 111 90387						
3,3 E	10%	4822 111 90447						
3,6 E	10%	4822 111 90389						
3,9 E	10%	4822 111 90391						
4,3 E	10%	4822 111 90392						
4,7 E	5%	5322 111 90376						
5,1 E	10%	4822 111 90393						
5,6 E	10%	4822 111 90394						
6,2 E	10%	4822 111 90395						
6,8 E	5%	4822 111 90254						
7,5 E	10%	4822 111 90396						

10. OTHER PARTS


10-1. Front View



• Parts List

No.	Stock No. (J)	Stock No. (T)	Description
1	58339300	MDC1309D03	CD Door
2	58338800	MDK1365D00	Knob For "Open/Close"
3	58339200	MDK1366D30	Knob For "Play"
4	58341400	GDC1501219	Display
5	58339100	MDK1366D29	Knob For "Pause"
6	58338700	MDK1364D36	Knob For "Memory"
7	58339000	MDK1366D18	Music Search Knob
8	58338600	MDK1364D25	Knob For "Time/Track"

10-2. Top View




• Parts List

No.	Stock No. (J)	Stock No. (T)	Description
1	58337900	MDC1305D05	Front Panel
2	58346800	MSB1583D08	Rear Cover
3	58338100	MDC1306D02	Side Panel (L)
4	58338200	MDC1307D09	Side Panel (R)
5	58341100	GPA0001D09	CD P.C.B & Deck
6	58340900	GTP0177D05	Power Transformer
7	58340500	MEJ1262F04	3 Pin AC Connector

11. PACKING LIST

No.	Stock No. (J)	Stock No. (T)	Description
1	58337700	MPW1080D01	Poly Bag For Set
2	58337600	MPP1258D01	Styrofoam Packing For Set
3	58337500	MPC1479D02	Carton Case




12. ACCESSORY LIST

No.	Stock No. (J)	Stock No. (T)	Description
1	58342800	MEJ1085D16	RCA Jack Wire
2	58337800	MDL2329D02	Instruction Book

HI-FI SPEAKER SYSTEM


SANSUI S-U1



Specifications

Speakers	2-way 2-speaker-type
Woofer.....	165 mm (6-1/2") Cone-type
Tweeter.....	50 mm (2") Cone-type
Maximum input power	25 Watts
Maximum Peak input Power	35 Watts
Impedance	4 ohms
Sensitivity	86 dB/W (at 1 m)
Frequency range	50 to 20,000 Hz
	(in normal listening room)
Crossover frequencies	2,000 Hz, 5,000 Hz
Dimensions	196 mm (7-3/4") W
	364 mm (14-1/3") H
	168 mm (6-2/3") D
Weight	3.45 kg (7.59 lbs) net
	7.4 kg (16.3 lbs) twin packed

1. FRONT VIEW




• Parts List

No.	Stock No. (J)	Stock No. (T)	Description
1	58343200	MDC1312D05	Front Cover
2	58343600	GSP4612D37	Speaker 4 ohm 35W 6-1/2"
3	58343700	GSP4712D30	Speaker 4 ohm 35W 2"

2. PACKING LIST

• Parts List

No.	Stock No. (J)	Stock No. (T)	Description
1	58343100	MPW1087D00	Poly Bag For Speaker
2	58343000	MPP1267D05	Styrofoam Packing
3	58342900	MPC1459D00	Carton Case





SANSUI ELECTRIC CO., LTD.:

SANSUI ELECTRONICS CORPORATION:

SANSUI ELECTRONICS (U.K.) LTD.:

SANSUI ELECTRONICS G.M.B.H.:

14-1, Izumi 2-chome, Suginami-ku, Tokyo Japan

PHONE: (03) 324-8891/TELEX: 232-2076 (International Division)

1250 Valley Brook Ave. Lyndhurst, N.J. 07071 U.S.A.

17150 South Margay Ave. Carson, California 90746 U.S.A.

3036 Koapaka Street. Honolulu, Hawaii 96819 U.S.A.

Unit 10A, Lyon Industrial Estate, Rockware Avenue, Geenford, Middx UB6, OAA, England

Pau Ehrich Strasse 8, 6074 Rödermark 2, West Germany