



Deze download wordt u gratis aangeboden door Pick-upnaalden.nl

Web : www.pickupnaalden.com
Email : info@pick-upnaalden.nl
Facebook : www.facebook.com/pickupnaalden
Twitter : twitter.com/Pickupnaalden
Google+ : https://plus.google.com/+FCaris_pickupnaalden

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PL-J230/ZDLEBM and PL-Z91/ZEBM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PL-Z91/ZEBM	PL-J230/ZDLEBM	
NSP	Sub-panel assembly	PXA1113	PXA1107	
	Speed button	PAC1226	PAC1726	
	EV button	PAC1227	PAC1724	
	S/S button	PAC1228	Not used	
	Cut button	Not used	PAC1722	
NSP	Front name plate	PAM1156	Not used	
	Badge	Not used	AAM1047	
	Dust cover	PNV1008	PNV1014	
	Under base	PNW1291	PNW2272	
	Arm assembly	PPD1016	PPD1031	
NSP	Cut rod	Not used	PBH1038	*
NSP	Size rod	PBH1039	Not used	
NSP	S/S rod	PBH1042	Not used	
	Protector (R)	PHA1045	PHA1233	
	Protector (L)	PHA1046	PHA1234	
	Button stopper F	PBK1038	Not used	
	Button stopper R	Not used	PBK1037	
	Packing case	PHG1163	PHG2116	
NSP	Panel	PNW1294	PNW2570	
	Start lever	PNW1293	Not used	
	PU plate assembly	PXA1109	Not used	
	PU plate (B) assembly	Not used	PXA1114	*

Note : Parts marked * are the same as those of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

SUB-PANEL ASSEMBLY

PXA1107 and PXA1113 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PXA1113	PXA1107	
	Select lever spring	PBH1053	Not used	
	Reset plate spring	PBH1054	Not used	
	Select lever	PNB1096	Not used	
	Index cam	PNW1296	Not used	
	Reset plate	PNW1312	Not used	
	Selector	PNW1313	Not used	
	Drive plate assembly	PXA1110	PXA1112 *	

Note : Part marked * is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

Service Manual

ORDER NO.
RRV1221

STEREO TURNTABLE

PL-J230

- Refer to the service manual ARP1478 for PL-Z91/ZEBM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PL-J230		
ZDLEBM	○	DC power supplied from other system component	

- This product is a system(s) component.

This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

This product's instructions are contained within the instruction manual of the related system component(s).

The manual is packed with those component(s).

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PL-J230/ZEBM and PL-Z91/ZEBM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PL-Z91/ZEBM	PL-J230/ZEBM	
NSP	Sub-panel assembly	PXA1113	PXA1107	
	Speed button	PAC1226	PAC1726	
	EV button	PAC1227	PAC1724	
	S/S button	PAC1228	Not used	
	Cut button	Not used	PAC1722	
NSP	Front name plate	PAM1156	Not used	
	Badge	Not used	AAM1047	
	Dust cover	PNV1008	PNV1013	
	Under base	PNW1291	PNW2272	
	Arm assembly	PPD1016	PPD1031	
NSP	Cut rod	Not used	PBH1038	*
NSP	Size rod	PBH1039	Not used	
NSP	S/S rod	PBH1042	Not used	
NSP	Protector (R)	PHA1045	PHA1233	
	Protector (L)	PHA1046	PHA1234	
	Button stopper F	PBK1038	Not used	
	Button stopper R	Not used	PBK1037	
	Packing case	PHG1163	PHG2117	
NSP	Panel	PNW1294	PNW2570	
	Start lever	PNW1293	Not used	
	PU plate assembly	PXA1109	Not used	
	PU plate (B) assembly	Not used	PXA1114	
				*

Note : Parts marked * are the same as those of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

SUB-PANEL ASSEMBLY

PXA1107 and PXA1113 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PXA1113	PXA1107	
	Select lever spring	PBH1053	Not used	
	Reset plate spring	PBH1054	Not used	
	Select lever	PNB1096	Not used	
	Index cam	PNW1296	Not used	
	Reset plate	PNW1312	Not used	
	Selector	PNW1313	Not used	
	Drive plate assembly	PXA1110	PXA1112 *	

Note : Part marked * is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

Service Manual

ORDER NO.
RRV1282

STEREO TURNTABLE

PL-J230

- Refer to the service manual ARP1478 for PL-Z91/ZEBM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PL-J230		
ZEBM	○	DC power supplied from other system component	

- This product is a system(s) component.

This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

This product's instructions are contained within the instruction manual of the related system component(s).

The manual is packed with those component(s).

Service Manual

ORDER NO.
RRV122 1

STEREO TURNTABLE

PL-J230

- Refer to the service manual ARP1478 for PL-Z91/ZEBM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PL—J230		
ZDLEBM	○	DC power supplied from other system component	

- This product is a system(s) component.

This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

This product's instructions are contained within the instruction manual of the related system component(s).

The manual is packed with those component(s).

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PL-J230/ZDLEBM and PL-Z91/ZEBM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PL-Z91/ZEBM	PL-J230/ZDLEBM	
NSP	Sub-panel assembly	PXA1113	PXA1107	
	Speed button	PAC1226	PAC1726	
	EV button	PAC1227	PAC1724	
	S/S button	PAC1228	Not used	
	Cut button	Not used	PAC1722	
NSP	Front name plate	PAM1156	Not used	
	Badge	Not used	AAM1047	
	Dust cover	PNV1008	PNV1014	
	Under base	PNW1291	PNW2272	
	Arm assembly	PPD1016	PPD1031	
NSP	Cut rod	Not used	PBH1038	*
NSP	Size rod	PBH1039	Not used	
NSP	S/S rod	PBH1042	Not used	
	Protector (R)	PHA1045	PHA1233	
	Protector (L)	PHA1046	PHA1234	
NSP	Button stopper F	PBK1038	Not used	*
	Button stopper R	Not used	PBK1037	
	Packing case	PHG1163	PHG2116	
	Panel	PNW1294	PNW2570	
	Start lever	PNW1293	Not used	
	PU plate assembly	PXA1109	Not used	*
	PU plate (B) assembly	Not used	PXA1114	

Note : Parts marked * are the same as those of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

SUB-PANEL ASSEMBLY

PXA1107 and PXA1113 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PXA1113	PXA1107	
	Select lever spring	PBH1053	Not used	
	Reset plate spring	PBH1054	Not used	
	Select lever	PNB1096	Not used	
	Index cam	PNW1296	Not used	
	Reset plate	PNW1312	Not used	
	Selector	PNW1313	Not used	
	Drive plate assembly	PXA1110	PXA1112 *	

Note : Part marked * is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

Service Manual

ORDER NO.
RRV1221

STEREO TURNTABLE

PL-J230

- Refer to the service manual ARP1478 for PL-Z91/ZEBM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PL-J230		
ZDLEBM	○	DC power supplied from other system component	

- This product is a system(s) component.

This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

This product's instructions are contained within the instruction manual of the related system component(s).

The manual is packed with those component(s).

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PL-J230/ZDLEBM and PL-Z91/ZEBM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PL-Z91/ZEBM	PL-J230/ZDLEBM	
NSP	Sub-panel assembly	PXA1113	PXA1107	
	Speed button	PAC1226	PAC1726	
	EV button	PAC1227	PAC1724	
	S/S button	PAC1228	Not used	
	Cut button	Not used	PAC1722	
NSP	Front name plate	PAM1156	Not used	
	Badge	Not used	AAM1047	
	Dust cover	PNV1008	PNV1014	
	Under base	PNW1291	PNW2272	
	Arm assembly	PPD1016	PPD1031	
NSP	Cut rod	Not used	PBH1038	*
NSP	Size rod	PBH1039	Not used	
NSP	S/S rod	PBH1042	Not used	
	Protector (R)	PHA1045	PHA1233	
	Protector (L)	PHA1046	PHA1234	
NSP	Button stopper F	PBK1038	Not used	*
	Button stopper R	Not used	PBK1037	
	Packing case	PHG1163	PHG2116	
	Panel	PNW1294	PNW2570	
	Start lever	PNW1293	Not used	
	PU plate assembly	PXA1109	Not used	*
	PU plate (B) assembly	Not used	PXA1114	

Note : Parts marked * are the same as those of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

SUB-PANEL ASSEMBLY

PXA1107 and PXA1113 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PXA1113	PXA1107	
	Select lever spring	PBH1053	Not used	
	Reset plate spring	PBH1054	Not used	
	Select lever	PNB1096	Not used	
	Index cam	PNW1296	Not used	
	Reset plate	PNW1312	Not used	
	Selector	PNW1313	Not used	
	Drive plate assembly	PXA1110	PXA1112 *	

Note : Part marked * is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

Service Manual

ORDER NO.
RRV1282

STEREO TURNTABLE

PL-J230

- Refer to the service manual ARP1478 for PL-Z91/ZEBM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PL-J230		
ZEBM	○	DC power supplied from other system component	

- This product is a system(s) component.

This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

This product's instructions are contained within the instruction manual of the related system component(s).

The manual is packed with those component(s).

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PL-J230/ZEBM and PL-Z91/ZEBM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PL-Z91/ZEBM	PL-J230/ZEBM	
NSP	Sub-panel assembly	PXA1113	PXA1107	
	Speed button	PAC1226	PAC1726	
	EV button	PAC1227	PAC1724	
	S/S button	PAC1228	Not used	
	Cut button	Not used	PAC1722	
NSP	Front name plate	PAM1156	Not used	
	Badge	Not used	AAM1047	
	Dust cover	PNV1008	PNV1013	
	Under base	PNW1291	PNW2272	
	Arm assembly	PPD1016	PPD1031	
NSP	Cut rod	Not used	PBH1038	*
NSP	Size rod	PBH1039	Not used	
NSP	S/S rod	PBH1042	Not used	
NSP	Protector (R)	PHA1045	PHA1233	
	Protector (L)	PHA1046	PHA1234	
	Button stopper F	PBK1038	Not used	
	Button stopper R	Not used	PBK1037	
	Packing case	PHG1163	PHG2117	
NSP	Panel	PNW1294	PNW2570	
	Start lever	PNW1293	Not used	
	PU plate assembly	PXA1109	Not used	
	PU plate (B) assembly	Not used	PXA1114	

Note : Parts marked * are the same as those of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.

SUB-PANEL ASSEMBLY

PXA1107 and PXA1113 have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		PXA1113	PXA1107	
	Select lever spring	PBH1053	Not used	
	Reset plate spring	PBH1054	Not used	
	Select lever	PNB1096	Not used	
	Index cam	PNW1296	Not used	
	Reset plate	PNW1312	Not used	
	Selector	PNW1313	Not used	
	Drive plate assembly	PXA1110	PXA1112 *	

Note : Part marked * is the same as that of PL-Z81/ZEBM which is shown with PL-Z91/ZEBM in the service manual ARP1478.